


# Blohm + Voss Oil Tools, LLC

9GF-1102 Cantilever Style FloorHand with  
9FM-2050 Hydraulic Lift

Technical Documentation



To be used with Serial Numbers 200+

# GENERAL INFORMATION

## Warnings and Notes

**WARNING: A "WARNING" INDICATES A DEFINITE RISK OF EQUIPMENT DAMAGE OR DANGER TO PERSONNEL. FAILURE TO OBSERVE AND FOLLOW PROPER PROCEDURES COULD RESULT IN SERIOUS OR FATAL INJURY TO PERSONNEL, SIGNIFICANT PROPERTY LOSS, OR SIGNIFICANT EQUIPMENT DAMAGE.**

**NOTE:** A "NOTE" indicates that additional information is provided about the current topics.

### Intended use of this manual

**WARNING: THIS TECHNICAL DOCUMENTATION CONTAINS INSTRUCTIONS ON SAFETY, INSTALLATION, OPERATION AND MAINTENANCE. IT MUST BE STUDIED BEFORE WORKING WITH THE TOOL.**

This manual is intended for use by field service, engineering, installation, operation, and repair personnel. Every effort has been made to ensure the accuracy of the

information contained herein. Blohm + Voss Oil Tools, LLC, will not be held liable for errors in this material, or for consequences arising from misuse of this material. Anyone using service procedures or tools, whether or not recommended by Blohm + Voss Oil Tools, LLC, must be satisfied that neither personal safety nor equipment safety will be jeopardized.

### Intellectual property

All rights retained. No part of this document may be reproduced in any form (print, photocopy, microfilm or any other procedure) or be processed using an electronic system without written approval of Blohm + Voss Oil Tools, LLC

All information contained in this manual is based upon the latest product information available at the time of printing. Dependent on ongoing technical improvements (ISO 9001) "Blohm + Voss Oil Tools, LLC" reserves the right to change the design

and specifications without announcement.

The values specified in this manual represent the nominal values of a unit produced in series. Slight deviations in the case of the individual devices are possible.

**NOTE: In the event of problems that cannot be solved with the aid of this manual, please contact one of the addresses listed below.**

### General remarks

As with all rig equipment, the FloorHand must be operated in accordance with accepted rig safety practices and procedures. All operators should be familiar with all safety precautions and recommended installation and operating procedures, including the information provided in this manual and any other safety publications by Blohm + Voss Oil Tools, LLC Listed on the next page are safety considerations and warnings found throughout this manual:

### CE Marking

The tool complies with the Machinery Directive 2006/42/EC and the Directive 2014/34/EU "Equipment and protective systems in potentially explosive atmospheres" The marking is as follows: CE Ex II 2G T5

### Patents

The following patent numbers apply:  
U.S. 11/404,317  
U.S. 11/890,582  
U.S. 11/732,813

### Limited Warranty

The warranty provided will be void if the FloorHand is either:

1. Repaired or serviced by a service facility which was not authorized by Blohm + Voss Oil Tools, LLC.
2. Replacement parts not manufactured by Blohm + Voss Oil Tools, LLC are used.
3. Modifications were made to the FloorHand which were not approved by Blohm + Voss Oil Tools, LLC.

## Manufacturer & Agents World Wide

Blohm + Voss Oil Tools  
Hermann-Blohm-Straße 2  
20457 Hamburg, Germany

Phone: +49(0)40/3119-1826/1162  
Fax: +49(0)40/3119-8194  
oiltools@blohmvooss.com  
www.blohmvooss-oiltools.com

Blohm + Voss Oil Tools, LLC  
7670 Woodway, Suite 266 Houston, Texas  
77063  
United States of America

Phone: +1-713-952-0266  
Fax: +1-713-952-2807  
BVOT@blohmvooss.com  
www.blohmvooss-oiltools.com

Premier Sea & Land Pte. Ltd.  
Shaw Centre  
1, Scotts Road #19-12  
228208 Singapore  
Republic of Singapore

Phone: +65-6734-7177  
Fax: +65-6734-9115  
enquiries@mtqpremier.com.sg

## Safety issues

**WARNING: ONE SHOULD AVOID CREATING IGNITION SOURCES, LIKE HEAT, AS A RESULT OF THE USE OF THE TOOL WITH OTHER TOOLS OR EQUIPMENT.**

**WARNING: THE WARNING PLATES, SIGNS AND LABELS MUST BE PRESENT ON THE TOOL. DO NOT REMOVE THE LABELS. IF THEY ARE MISSING, REPLACING IS MANDATORY.**

**WARNING: ALL WARNING PLATES, SIGNS AND LABELS ATTACHED TO THE EQUIPMENT MUST BE OBSERVED.**

**WARNING: DO NOT USE THE TOOL FOR ANY OTHER PURPOSE THAN MAKING UP AND BRAKING OUT WITHIN ITS SPECIFICATION.**

**WARNING: FAILURE TO CONDUCT ROUTINE MAINTENANCE COULD RESULT IN EQUIPMENT DAMAGE OR INJURY TO PERSONNEL.**

**WARNING: THE TOOL MUST ONLY BE SERVICED BY TRAINED B+V PERSONNEL OR BY AUTHORIZED PERSONNEL.**

**WARNING: WHILE WORKING WITH THE EQUIPMENT, WEAR PERSONAL PROTECTION EQUIPMENT.**

**WARNING: IF ANY SAFETY ELEMENTS (LIKE SAFETY ROPES, WIRE, SAFETY SHEETS, PLATES OR WASHERS) WERE DISASSEMBLED DUE TO MAINTENANCE WORK, DO**

**NOT RE-USE THEM. ALWAYS REPLACE THEM WITH NEW SAFETY ELEMENTS.**

**WARNING: KEEP HANDS AND ARMS CLEAR OF ALL MOVING PARTS WHEN CONNECTING, DISCONNECTING OR OPERATING THE UNIT.**

**WARNING: ALWAYS WEAR PROTECTIVE GEAR FOR EYES, HEAD, HANDS AND FEET.**

**WARNING: WHEN SERVICING UNIT, BE SURE ALL POWER IS OFF AND SUPPLY LINES ARE DISCONNECTED AND INTERNAL PRESSURE IS BLED FROM THE TOOL.**

**WARNING: LUBRICATE UNIT ONLY WHEN SUPPLY LINES ARE DISCONNECTED AND H.P.U IS OFF AND TAGGED OUT. VERIFY THAT SYSTEM PRESSURE IS -0- PSI.**

**WARNING: ALWAYS USE LIFTING APPARATUS (SLINGS, CABLES, SHACKLES AND THE LIKE) THAT HAVE BEEN INSPECTED AND ARE IN GOOD CONDITION AND ARE PROPERLY SIZED. ENSURE THAT ALL RIGGING AND LIFTING PROCEDURES ARE IN ACCORDANCE WITH ACCEPTED OILFIELD PRACTICES AND STANDARDS.**

**WARNING: ALWAYS CHECK THE UNIT FOR LOOSE FASTENERS AND HYDRAULIC CONNECTIONS AS WELL AS ANY OTHER DAMAGE PRIOR TO TURNING ON THE POWER UNIT.**

## Revision History Table

REV.	SECTION	SUB-SEC.	PARA.	CHANGE REQUEST #	DATE	AUTHORIZED BY
Draft	All	All	All	N/A	10/01/10	KJ
0	All	All	All	N/A	03/19/12	KJ

TABLE OF CONTENTS	TABLE OF CONTENTS	
DESCRIPTION	<b>TABLE OF CONTENTS</b>	<b>4</b>
	<b>DESCRIPTION</b>	<b>6</b>
	General Components	7
	Wrenches	7
COMMISSIONING	Spinner	7
	Frame	7
	Controls	7
	Lift Cylinder	8
	Specifications	9
INSTALLATION	Hydraulic Requirements	9
	Shipping Data (Approximately allowing for crate or pallet)	9
	<b>COMMISSIONING</b>	<b>12</b>
	FloorHand Commissioning Procedure	14
OPERATIONS	<b>INSTALLATION</b>	<b>17</b>
	Normal Rig Move Removal and Installation	18
	Lifting	18
	Attaching to the Lift Cylinder	19
	Locating the HPU and attaching the Hydraulic Lines	19
MAINTENANCE & INSPECTION	Attaching the Hydraulic Lines	20
	Make Up Torque Adjustment	21
	Rig-Up/ Rig-Down	22
	FloorHand Wrench Torque Chart	23
SPARE PARTS	<b>OPERATIONS</b>	<b>24</b>
	Controls	25
	Making a Connection	27
	Breaking a Connection	35
	Troubleshooting	41
DRAWINGS	<b>MAINTENANCE &amp; INSPECTION</b>	<b>50</b>
	Grease Quality	51
	Lubrication	51
	Removal of Die-block	54
	Replacement of Tong Dies	54
INDEX	Replacement of Centering Buttons	55
	Replacing Spinner Drive Rollers	56
	Frequency	59
	Inspection	59



Hydraulic System Inspection	59
Dismantling Inspection	59
Check Category I (Ongoing Observation)	60
Check List Category II (Daily)	60
Check List Category III (Every Year)	61
Check List Category IV (Every 2 years)	61
Inspection Categories acc. to API RP 8B	62
Periodic Inspection	62
Inspection Check Lists	63
<b>SPARE PARTS</b>	<b>64</b>
Recommended Spare Parts for One Year Operation	65
<b>DRAWINGS</b>	<b>66</b>
CANTILEVER STYLE FLOORHAND WITH 9FM-2050 HYDRAULIC CYLINDER	68
CANTILEVER FRAME ASSEMBLY	9FH-10001 69
FLOORHAND COMBINATION MANIFOLD	9FH-01539 72
FLOORHAND RETURN MANIFOLD	9FH-01540 73
SPINNER SUB ASSEMBLY	9FH-10302 74
DOUBLE DRIVE ROLLER ASSEMBLY	9FH-01407 76
IDLER GEAR ASSEMBLY	9FH-01287 77
DRIVE ROLLER GEAR ASSEMBLY	9FH-01408 78
UPPER WRENCH SUB ASSEMBLY ORFS	9FH-10201 79
REMOVABLE SPINNER POST ASSEMBLY	9FH-01520 82
LOWER WRENCH SUB ASSEMBLY ORFS	9FH-10101 83
DIE BLOCK ASSEMBLY	9FH-01060 85
2-7/8 ADAPTER KIT ASSEMBLY	9FH-10703 86
2-7/8 DIE BLOCK ADAPTER ASSEMBLY	9FH-01445 87
WINCH AND MOUNTING ASSEMBLY	9FH-10701 88
SERVICE KIT	9FH-10841 89
LOW RANGE TORQUE CYLINDER CHART	90
FLOORHAND COMPLETE HYDRAULIC SCHEMATIC	91
HYDRAULIC SCHEMATIC	92
<b>INDEX</b>	<b>93</b>

DESCRIPTION	DESCRIPTION
-------------	-------------

## General Components

The Blohm + Voss Oil Tools, LLC FloorHand is a combination torquing and spinning tool designed for quick installation on a variety of drilling rigs. This manual covers the basic FloorHand 9GF-1102 including the 9FM-2050 Hydraulic Lift Cylinder.

The FloorHand can make and break all tool connections from 4 ¼” to 8 ½” outside diameter, and can handle nominal drill pipe from 3 ½” up to 6 ⅝” without any modification. (To handle 2 ⅞” drill pipe, Blohm + Voss is able to provide an optional adapter kit assembly. Please contact Blohm + Voss Oil Tools, LLC for prices on the 9FH-10703 adapter kit. The FloorHand can also make and brake stabilizers, spiral collars and other bottom hole assembly (BHA) components with sufficient connection length.

## Wrenches

The FloorHand utilizes an upper and a lower wrench designed to apply torque when making up or breaking out tool joint connections. Each wrench contains an opposing set of clamp cylinders and Die Block assemblies that self adjust to varying pipe sizes. The FloorHand is capable of 65,000 ft-lbs (88,128.16 Nm) of make up torque and 80,000 ft-lbs (108,465.40 Nm) of break out torque.

## Spinner

The FloorHand is equipped with a spinner that consists of two halves, a right and a left hand assembly each containing a set of urethane drive rollers. The spinner uses direct drive gears, eliminating the need for expensive transmissions. The FloorHand spinner is designed to be field serviceable and easily maintained by rig personnel.

## Frame

The cantilever frame is designed to support and house the wrench and spinner assemblies.

## Controls

The all-hydraulic controls for the FloorHand is mounted conveniently on the front of the unit for easy access as well as maximum visibility for the operator.

## Lift Cylinder

The Blohm + Voss Oil Tools, LLC Lift Cylinder 9FM-2050) provides working stroke length of the 36" (91.4 cm). The rated pressure for the cylinder is 3,000 psi (20,684.27 kPa). The cylinder has a maximum extend capacity of 4,915 lbs (415.91 kgs) and a maximum retracting capacity of 9,420 lbs (4,272.73 kgs) at 3,000 psi (20,684.27 kPa).




Figure 1

# Specifications

## Hydraulic Requirements

Hydraulic supply pressure (max.)	2,800 psi (19.30 MPa) - 193 bar
Hydraulic supply pressure (min.)	2,500 psi (17.23 MPa) - 172 bar
Hydraulic flow rate required	23 - 28 gpm (87 - 106 lpm)
Supply connection (min.)	1" hose with ¾" MNPT at FloorHand end
Return connection (min.)	1 ¼" hose with 1" MNPT at FloorHand end

The FloorHand is equipped with a Closed Center Hydraulic System. The unit should only be operated in coordination with a pressure compensated variable displacement Hydraulic Power Source.

**WARNING: USE OF A CONSTANT DISPLACEMENT PUMP WILL RESULT IN DAMAGE AND/OR FAILURE THUS VOIDING WARRANTY.**

## Wrench Assembly:

Motor spinning roller ratio	1: 1.25
Spin speed ( <i>rollers</i> )	105 - 110 rpm
Spin speed (8 ½" O.D.)	80 - 100 rpm
Make up torque	11,000 ft-lb min. ( <i>w/o optional low torque system</i> ) (14,913 Nm)
	65,000 ft-lb max. (88,128.16 Nm)
Break out torque	80,000 ft-lb max. (108,465.40 Nm)

## Shipping Data (Approximately allowing for crate or pallet)

Length	50 inches	(1,270 mm)
Width	60 inches	(1,524 mm)
Height	60 inches*	(1,524 mm)
Weight	4,550 lbs	(2,068.18 kg)




Figure 2



## EG-Konformitätserklärung EC-Declaration of Conformity

Wir (we)

Blohm + Voss Oil Tools, LLC  
11355 FM 830  
Willis, TEXAS 77318  
USA

erklären in alleiniger Verantwortung, dass das Produkt  
hereby declare in our sole responsibility, that the product

### BVOT hydraulic make-up/break-out wrench and spinner combination

2-7/8" DP (min. 4" TJ) - 8-1/2" DC Make-up Torque: 65,000 Ft Lbs

auf das sich diese Erklärung bezieht, mit der/den folgenden Norm(en) oder  
normitativten Dokumenten übereinstimmt

which is the subject of this declaration, is in conformity with the following standard(s) or  
normative documents

#### Bestimmungen der Richtlinie:

terms of the directive:	Title and/or No. and date of issue of the standard
Richtlinie 2006/42/EG des Europäischen Parlaments und des Rates vom 17 Mai 2006 über die Angleichung der Rechtsvorschriften von 2006 der Mitgliedstaaten für Maschinen.	Maschinenrichtlinie 2006/42/EG 17 Mai 2006
Directive 2006/42/EG of the European Parliament and of the Council of 17 May 2006 on the approximation of the laws of 2006. The Member States relating to machinery.	Machinery Directive 2006/42/EG 17 May 2006
Sicherheit von Maschinen. - Teil 1 und 2 Safety of machinery, part 1 and 2	DIN EN ISO 12100:2009.10 DS EN ISO 12100:2009.07
Sicherheit von Maschinen - Leitsätze zur Safety of machinery, Risk assessment	DIN EN ISO 14121-1:2007.12 DS EN ISO 14121-1:2007.12
Ausrüstung für Bohr- und Bohrlocharbeiten Petroleum and natural gas industries-Drilling and well-servicing equipment	DIN EN ISO 14693:2005.07 ISO 14693 / API 7K 5th Edition:2010.06
Geräte und Schutzsysteme zur bestimmungsgemäßen Verwendung in explosionsgefährdeten Bereichen	EG Richtlinie 94/9/EG (ATEX 95)
Devices and protection systems fot intended use in explosive	EG Richtlinie 94/9/EG (ATEX 95)
Nicht-elektrische Geräte für den Einsatz in explosionsgefährdeten Bereichen	DIN EN 13463-1:2009-07
Non-electrical equipment for use in potentially explosive atmospheres	DIN EN 13463-1:2009-07

Das Gerät „FLOORHAND hydraulisch betrieben“ erfüllt die Maschinenrichtlinie 2006/42/EC und erfüllt die EG Richtlinie 94/9/EG.

The product „FLOORHAND hydraulic operated“ complies with the Machinery Directive 2006/42/EC and complies with the EC Guideline 94/9/EG.

Kennzeichnung:

Mark:

Location and Date

Blohm+Voss Oil Tools, LLC

11355 FM 830

Willis, TEXAS 77318

USA

E-Mail: [sales@bvot.us](mailto:sales@bvot.us)

Internet: [www.blohmvooss-oiltools.com](http://www.blohmvooss-oiltools.com)

CE Ex II 2G T5

*David R. Voss*

**Blohm + Voss Oil Tools, LLC**

11355 FM 830

Willis, Texas 77318

# COMMISSIONING

## Document Front Page

0	11/04/2010	FloorHand Shop Test/Commissioning Procedure	DT	CT	MT
Draft	10/28/1020	Issued	DT	CH	MT
Rev./Status	Date	Description	Made by	Checked By:	Approved:
			Supplier References:		
			Procurement References:		
			TAG NO:		
Date:	Signature:	SDRL Code:	Area:	System:	Pages:
Company:			Document Title/ Equipment:		
			Commissioning Check Sheet for FloorHand (Iron Roughneck)		
Rig/Vessle/Customer Order:			Equipment Serial No:		
Supplier:			Document No:		
Blohm + Voss Oil Tools, LLC					

# FloorHand Commissioning Procedure

This test procedure is to be performed by authorized B+V personnel only!

*Note: When performing the following steps, appropriate PPE will be used and standard safety practices must be followed at all times.*

*Note: When commissioning, H.P.U Commissioning must be completed prior to FloorHand commissioning. If installing FloorHand to customer supplied hydraulics, hoses must be flushed completely before connecting to FloorHand.*

## COMMISSIONING

1. \_\_\_\_ Connect FloorHand (using flow meter) to Hydraulic power source of 2,500-2,800 psi and 25-28 gpm. If pressure is above 2800 psi, a Pressure Release Valve (PRV) should be used. \_\_\_\_ If flow rate is above 28 gpm, a pressure compensated flow control should be used. \_\_\_\_

2. \_\_\_\_ H.P.U should be powered up a minimum of 20 minutes before moving to next step, to bring all oil to required operating oil temperature, record oil temp. \_\_\_\_

*Note: Throughout entire test, observe FloorHand for leaks, and or malfunctions, repair as necessary.*

3. \_\_\_\_ Run spinner motors in make direction for 20 seconds, check that rotation of all four rollers are correct, check for leaks. Monitor flow meter, record max flow. \_\_\_\_  
See step 1.

4. \_\_\_\_ Run spinner motors in break direction for 20 seconds, check for leaks.

*Note: After making fresh hydraulic connections, or a rig move, it is best to always run the spinner before anything else. The spinner is the only system that is close to a direct system. For example, there are no PRV's, check valves, shuttle valves, diverter valves, pilot operated check valves, etc. in the spinner motor system, only a flow divider. This means, by running the spinner first, any small trash or contaminants that may be in the lines, will be flushed through with minimal to no damage. If there were trash in the lines, and the torque, or clamp system were operated first, there is a chance of contaminants getting lodged in a small orifice, in one or more of the many valves in the other systems.*

5. \_\_\_\_ Without pipe, clamp and unclamp lower wrench 10 times, check that die blocks extend and retract evenly, check for leaks.

*Note: This helps to remove air from the lower clamp system so that the flow divider may work correctly.*

6. \_\_\_\_ Without pipe, clamp lower wrench.

7. \_\_\_\_ Clamp and unclamp upper wrench 10 times, check that die blocks extend and retract evenly, check for leaks.

8. \_\_\_\_ Unclamp lower wrench.

9. \_\_\_\_ Without pipe, clamp and unclamp spinner 10 times, check for leaks.

*Note: spinner may, or may not close evenly, this is normal.*

10. \_\_\_\_ Back torque adjustment knob out completely, then turn in (clockwise) 4 turns, Blohm + Voss Oil Tools, LLC.

11. \_\_\_\_ Actuate torque cylinder 10 complete strokes in each direction, check for leaks.

12. \_\_\_\_ Adjust make up speed flow control for a 5 second stroke. Verify during commissioning.

13. \_\_\_\_ Install test gauge on lower clamp cylinder outboard test port.

14. \_\_\_\_ Clamp lower wrench.

15. \_\_\_\_ Observe test gauge on lower wrench clamp cylinder, and Pressure Release Valve (PRV) if applicable.

16. \_\_\_\_ Set Pressure Release Valve (PRV) output to obtain 600 psi at lower clamp cylinder. Verify during commissioning.
17. \_\_\_\_ Clamp upper wrench, ensure that system pressure is now present on lower clamp cylinders also (PRV reading should not change), unclamp upper wrench, unclamp lower wrench.
18. \_\_\_\_ Mock up test pipe, with torque, at end of stroke, check that gauge dump valve functions correctly.
19. \_\_\_\_ Stall spinner in make direction and hold for 5 seconds, check for leaks.
20. \_\_\_\_ Stall spinner in break direction and hold for 5 seconds, check for leaks.
21. \_\_\_\_ Operate manipulator / lift cylinder full up & down 10 times to remove all air from cylinder and counterbalance valve, check for leaks. If commissioning, inform rig crew that this should be done after every rig-up.
22. \_\_\_\_ Raise manipulator / lift cylinder to mid stroke, check that counterbalance valve holds.
23. \_\_\_\_ If applicable, extend and retract manipulator full out and in 5 times, check for proper function, check for leaks.
24. \_\_\_\_ WARNING: Clamp lower wrench, verify that manipulator functions do not operate.
25. \_\_\_\_ Unclamp lower wrench.
26. \_\_\_\_ Connect test gauge to return system test port, run spinner motors and hold while checking pressure filter bypass indicator (if applicable), and monitoring system back pressure, not to exceed 250 psi. Record back pressure \_\_\_\_\_
27. \_\_\_\_ If applicable, check shutoff valve for proper function.
28. \_\_\_\_ Remove test gauges, and reattach cap ports.
29. \_\_\_\_ Install any panels / covers removed for test.
30. \_\_\_\_ Ensure rig personnel fully understand all functions and basic maintenance of the FloorHand, including but not limited to: Importance of keeping fresh dies installed, proper make up torque adjustment, proper breakout procedure. Demonstrate how to remove and install the following: Dies, die blocks, and drive rollers.

Tech: \_\_\_\_\_

Signature: \_\_\_\_\_

Date: \_\_\_\_\_

Technician:

Signature:

Date:

### Record of Training

COMMISSIONING

Name:	Areas of Training: (Lubrication/Frequency/PM,etc.)	Signature:	Date:
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
My signature above indicates that I have read and understand the opening instructions and have been trained to use the above machine by Blohm+Voss Oil Tools, LLC Technicians.			

Acknowledgement of Rig Superintendant / Tool Pusher

Date

Name

Signature

--	--	--

My signature above indicates acceptance of commissioning and the above personnel training.



# INSTALLATION

# Normal Rig Move Removal and Installation

## Lifting

The FloorHand 9GF-1102 and 9FM-2050 combination incorporates two lifting points on the uppermost area of the torque arm. The unit should always be lifted using a two part bridle, one leg of each bridle attached to one of the lifting points. Never lift the unit by a single leg.




Figure 3

## Attaching to the Lift Cylinder

The FloorHand is suspended by the lift cylinder (and an optional wench) by a suspension assembly and gimbal. This configuration allows the unit to float as well as swivel for maximum floor flexibility and performance. The suspension assembly and gimbal should always be left attached to the unit. The unit is delivered from the factory with the suspension shackles attached to the center holes of each frame bracket. This position is usually satisfactory, however the unit should be checked for level and adjust if required.

## Locating the HPU and attaching the Hydraulic Lines

The Hydraulic Power Unit (HPU) may be located some distance away from the rig floor and, unless the electric components on the HPU are explosion proof, **MUST** be located off of the rig floor and away from the danger zone. The supply and return hoses from the HPU are normally run up through the rig floor near the socket. The optional supply and return hoses are equipped with self-closing quick disconnect fittings. They attach to the mating quick disconnect fittings mounted on the back of the manipulator. Care must be taken during installation to minimize chafing of the hoses during rig up/rig down as well as during operation of the FloorHand. If the hoses chafe against the rig structure when the manipulator is moved, particularly when being slewed, chafe protection should be used. The remote start stop switch included with the Blohm + Voss 9PU-7200 HPU is explosion proof and may be located anywhere that is convenient to the Driller.



Figure 4

**WARNING: NEVER ALLOW PERSONNEL TO BE IN THE DIRECTION THAT THE EQUIPMENT MAY SWING WHEN BEING INSTALLED OR REMOVED. FAILURE TO DO SO MAY CAUSE INJURY TO PERSONNEL OR DAMAGE TO THE EQUIPMENT.**

**WARNING: ALWAYS USE LIFTING APPARATUS (SLINGS, CABLES, SHACKLES AND THE LIKE) THAT HAVE BEEN INSPECTED AND ARE IN GOOD CONDITION AND ARE PROPERLY SIZED. ENSURE THAT ALL RIGGING AND LIFTING PROCEDURES ARE IN ACCORDANCE WITH ACCEPTED INDUSTRY PRACTICES AND STANDARDS.**

**WARNING: NEVER STAND UNDER A LOAD BEING LIFTED.**

## Attaching the Hydraulic Lines

When replacing these fittings, it is imperative to use exactly the same fitting in exactly the same orientation consistent with the factory installation. Always ensure that the quick disconnect fittings are fully engaged and locked (if appropriate to the type of fitting used).

1. Attach the pressure line quick disconnect fitting from the manipulator to the pressure line fitting (the top fitting with the ball valve) at the top of the unit.
2. Attach the return line from the manipulator to the fitting (the lower fitting) at the top of the unit.
3. Attach the four smaller lines from the manipulator to the appropriate lines on the unit.
4. Bleeding the system prior to use

### Procedure:

1. Operate all handles for a number of times; allow the tool to move completely to its hard stops.
2. Spin and torque a piece of pipe

**WARNING: THE QUICK DISCONNECT FITTINGS ARE CONFIGURED BY THE SIZE SO THERE IS NO POSSIBILITY OF ATTACHING THE LINES INCORRECTLY.**

**WARNING: ALWAYS MAKE SURE THAT ALL OF THE CONTROL VALVE HANDLES FOR CLAMP (LOWER WRENCH, UPPER WRENCH AND SPINNER CLAMP) FUNCTIONS ARE IN THE FULLY RETRACTED POSITION PRIOR TO TURNING ON THE POWER UNIT.**

**WARNING: PRIOR TO USE OF FLOORHAND AND THE LIFT CYLINDER ALWAYS ENSURE NO AIR IS EXISTING IN THE HYDRAULIC CIRCUITS. HAVING AIR IN THE LINES CAN CAUSE UNEXPECTED MOVEMENTS OF FLOORHAND AND THE LIFT CYLINDER.**




Figure 5

## Make Up Torque Adjustment

To make up a connection for the first time, it is necessary to set the make up torque to the proper setting for the given tool joint, as per appropriate specifications from either the well plan or from the drill pipe manufacturer. Referring to normal make up procedures, it is assumed that the unit is engaged with the lower wrench clamped on the box and the pin has been spun up and shouldered. The make up torque adjustment is as follows:

1. Locate the "Torque Adjustment" control knob on the control panel below the torque gauge and break free the lock knob. Then rotate the adjustment knob counter clockwise until it stops. This decreases the available pressure in the torque circuit to a minimum.
2. With the upper wrench unclamped, move the "torque" handle on the main control valve to rotate the upper wrench fully to the break out position (that is, where the torque cylinder is fully extended).
3. Push the "upper clamp" handle on the main control valve to clamp the upper wrench on the pin end of the tool joint.
4. Pull and hold the "torque" handle on the main control valve. The upper wrench may or may not begin to move in the direction of make up. While holding the "torque" handle, rotate the "Torque Adjustment" control knob on the control panel clockwise to increase the torque until the reading on the torque gauge reaches the desired setting and stops moving. Hold for 3 seconds. Do not over torque the joint.
5. Lock in torque adjustment by gently tightening the locking knob. Do not over tighten. Once the unit has been properly adjusted, it is usually not necessary to re-adjust under normal conditions. At each connection, the operator should verify that the torque gauge stops at the proper setting for the particular tool joint. If it does not, the unit must be re-adjusted.



Figure 6



Figure 7

### NOTE:

IF, AT ANY TIME, THE TORQUE PRESSURE DROPS DURING THE MAKEUP PROCEDURE, THIS MEANS THAT THE CYLINDER IS OUT OF STROKE. THE UPPER WRENCH SHOULD BE UNCLAMPED AND ANOTHER BITE SHOULD BE TAKEN.

## Rig-Up/ Rig-Down

- Attach a two part lifting bridle to the lifting eyes on the uppermost portion of the frame bracket using properly sized shackles. Attach one leg of the bridle to each bracket.
- Take up the slack in the lifting bridle until the suspension assembly is just loose.
- Remove the safety pin from the gimbal pin.
- Supporting the weight of the gimbal and suspension, remove the gimbal pin and lower the gimbal and suspension to rest on the frame.
- Replace the gimbal pin and safety pin.
- Lift the unit with the bridle.
- The installation of the unit is the reverse of the removal.



# FloorHand Wrench Torque Chart




Figure 8

# OPERATIONS

## Controls

The controls for the manipulator and wrench are situated on the front left corner of the upper wrench.




Figure 9

These two images show where the pipe needs to be positioned within the FloorHand.




Figure 10




Figure 11



## Making a Connection

**WARNING:** BEFORE OPERATING THE UNIT, MAKE SURE THAT YOU HAVE READ AND UNDERSTAND THIS ENTIRE MANUAL AND HAVE BEEN PROPERLY TRAINED IN THE OPERATION OF THE UNIT. ALSO VERIFY THAT THE UNIT HAS BEEN PROPERLY INSPECTED, ADJUSTED AND LUBRICATED BEFORE EACH USE.

**WARNING:** ALWAYS CLAMP THE LOWER WRENCH BEFORE CLAMPING THE UPPER WRENCH OR SPINNER.

**WARNING:** DO NOT CLAMP THE FLOORHAND ONTO THE PIPE BEFORE THE PIN HAS BEEN STABBED.




Figure 12

1. Slowly pull the "Lift" handle to raise the FloorHand approximately 2 to 3 feet from the rig floor.

**WARNING:**  
NEVER ALLOW YOURSELF OR SOMEONE ELSE TO BE BETWEEN THE FLOORHAND AND THE PIPE, OR ANY FIXED OBJECT.

**NOTE:**  
REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.



Figure 13

2. Once you have ensured that the operating area is clear, pull the "Extend" handle to move the FloorHand out to the pipe. Release the "Extend" handle when the tool approaches the pipe center.



Figure 14

3. Release the "Extend" handle when the tool approaches the pipe center.




Figure 15

4. Use the "Extend" handle to center the tool in and out first.

**NOTE:**  
ALWAYS CENTER BY EXTENDING FIRST AND THEN  
CENTER BY MOVING UP AND DOWN!



Figure 16

5. Use the lift handle to center the top of the box with the pivot center of the tool (see photo).






Figure 17

6. Once the FloorHand is centered on the Tool joint, clamp the lower wrench onto the box.

**NOTE:**  
REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.

**NOTE:**  
STAY CLEAR OF HARDBAND!



Figure 18

7. **TECHNICAL NOTE:** When clamped alone, the lower wrench clamps at approximately 600 psi. This prevents the box from becoming deformed before the pin is spun in.




Figure 19

8. Make sure not to clamp on the upset or tool joint taper.



Figure 20

9. Clamp the spinner on the pipe by pushing the spin clamp handle.

**NOTE:**  
REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.



Figure 21

10. Pull the spinner handle to "Spin In".



Figure 22

11. Shoulder up pin with spinner.





Figure 23

12. Pull the spinner clamp handle to unclamp the spinner.

**NOTE:**  
REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.




Figure 24

13. Push the torque handle to clock the upper wrench to the full break out position (counter clockwise) to ready the wrench for a full make up stroke.



Figure 25

14. Clamp the upper wrench on the tool joint by pushing the upper wrench clamp handle.

**NOTE:**  
REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.

**NOTE:**  
STAY CLEAR OF HARBAND!



Figure 26

15. Unlock the torque adjustment locking knob.

**NOTE:**  
NO OTHER ADJUSTMENT SHOULD BE NECESSARY UNLESS THE PIPE SIZE OR SPECIFIED TORQUE CHANGES. HOWEVER, TORQUE SHOULD BE MONITORED ON EVERY CONNECTION.




Figure 27

16. Rotate the torque adjustment knob full counter clockwise.

**NOTE:**  
THIS IS THE ABSOLUTE MINIMUM SETTING, AND SHOULD ALWAYS BE USED AS THE STARTING POINT WHEN ADJUSTING THE TORQUE.



Figure 28

17. Pull and hold the torque in the makeup direction.

**NOTE:**  
TOOL WILL NOT MOVE MUCH IF ANY, AS MINIMUM PRESSURE IS BEING SENT TO TORQUE CYLINDER.





Figure 29

18. While holding the torque handle fully in the makeup direction, slowly turn the torque adjustment knob clockwise until the desired torque (marked in black on the gauge) is reached. When torque is reached, hold for 3 seconds; tighten the torque adjustment lock knob to hold the torque setting. (DO NOT OVER TIGHTEN)

*NOTE: THERE IS APPROXIMATELY TWO TURNS OF DEAD SPACE IN THE TORQUE ADJUSTMENT KNOB.*

*NOTE: IF THE TORQUE NEEDLE FALLS OFF, THE CYLINDER IS AT THE END OF ITS STROKE. IT IS NOW NECESSARY TO UNCLAMP THE UPPER WRENCH AND PERFORM ANOTHER MAKE UP CYCLE. (REPEAT TORQUE CYCLE)*

*NOTE: TORQUE ON ALL CONNECTIONS SHOULD BE HELD AND VERIFIED FOR A MINIMUM OF 3 SECONDS.*



Figure 30

19. Unclamp the upper wrench by pulling the upper wrench unclamp handle.

*NOTE: REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.*



Figure 31

20. Unclamp the lower wrench by pulling the lower wrench unclamp handle.



Figure 32

21. Ensure all is clear and move the tool away from the pipe to the full retracted position.

**NOTE:**  
REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.



Figure 33

22. Lower the FloorHand to its full seated position.

**NOTE:**  
IT IS GOOD PRACTICE TO LOWER THE TOOL COMPLETELY AFTER EVERY CYCLE TO REDUCE INTERFERENCE WITH TOP DRIVE SERVICE LOOP OR KELLY HOSE.



## Breaking a Connection



Figure 34

1. Slowly pull the "Lift" handle to raise the FloorHand approximately 2 to 3 feet from the rig floor.

**WARNING:**  
NEVER ALLOW YOURSELF OR SOMEONE ELSE TO BE BETWEEN THE FLOORHAND AND THE PIPE, OR ANY FIXED OBJECT.

**NOTE:**  
REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.



Figure 35

2. Ensure the operating area is clear, then pull the "Extend" handle to move the FloorHand out to the pipe. Release the "Extend" handle when the tool approaches the pipe center.




Figure 36

3. Use the "Extend" handle to center the tool in and out first.

**NOTE:**  
ALWAYS CENTER BY EXTENDING FIRST AND THEN CENTER BY MOVING UP AND DOWN!





Figure 37

4. Use the "Lift" handle to center the tool VERTICALLY on the tool joint.



Figure 38

5. Once the FloorHand is centered on the tool joint, clamp the lower wrench onto the box by pushing the lower wrench clamp handle.

**NOTE:**  
**STAY CLEAR OF HARBAND!**

**NOTE:**  
**REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.**



Figure 39

6. Pull the torque handle to place the wrench in a position that will allow for a full breakout stroke.




Figure 40

7. Clamp the upper wrench by pushing the upper wrench clamp handle.

**NOTE:**  
**STAY CLEAR OF HARBAND!**

**NOTE:**  
**REMEMBER TO ALWAYS KEEP YOUR FREE HAND ON THE GREEN SAFETY HANDLE.**




Figure 41

8. Gently move the torque handle to the right to slowly break the connection.

**NOTE:**  
**THERE IS NO ADJUSTMENT FOR BREAK OUT TORQUE PRESSURE. THEREFORE, THE BREAKOUT CYLINDER GETS FULL PRESSURE AND FLOW.**

**NOTE:**  
**IN HIGH TORQUE SITUATIONS, IF THE BREAKOUT HANDLE IS SHIFTED FULLY, THE DIES MAY BREAK OR THE UPPER WRENCH COULD SLIP, THUS DAMAGING THE TOOL JOINT.**




Figure 42

9. Once the connection breaks, the handle may be shifted fully to the right to finish the breakout stroke at full speed.

**NOTE:**  
**IT WILL SOMETIMES BE NECESSARY TO BREAKOUT TWICE BEFORE THE SPINNER CAN TAKE OVER.**





Figure 43

10. After the breakout is complete, unclamp the upper wrench.

**NOTE:**  
YOU MAY NOW CENTER THE UPPER WRENCH  
HOWEVER THIS IS NOT NECESSARY.




Figure 44

11. Clamp the spinner by pushing the spin clamp handle. Stay clear of the upset and tool joint taper.




Figure 45

12. Push the spin motor handle to the right, fully, to spin out the pin.



Figure 46

13. Pull the spin clamp handle to unclamp the spinner.



Figure 47

14. Unclamp the lower wrench.



Figure 48

15. Ensure all is clear and move the tool away from the pipe to the full retracted position.




Figure 49


16. Lower the FloorHand to its full seated position.

**NOTE:**  
IT IS GOOD PRACTICE TO LOWER THE TOOL COMPLETELY AFTER EVERY CYCLE TO REDUCE INTERFERENCE WITH TOP DRIVE SERVICE LOOP AND OR KELLY HOSE.




## Troubleshooting

### Problem: Upper wrench slips when making or breaking a connection.




## Problem: Lower wrench slips when making or breaking connections.






## Problem: After Manipulator / Lift Cylinder is raised, FloorHand slowly drifts down.




**START**




## Problem: Transport pin cannot be installed, holes do not line up.




## Problem: All wrench & manipulator functions are inoperative.



## Problem: Die block extends, but will not retract on its own.



## Problem: Manipulator / Lift Cylinder does not function.



# MAINTENANCE & INSPECTION



## Grease Quality

In order to achieve efficient lubrication even at different environmental temperatures, we recommend that the following grease types be used:

*WARNING: ALWAYS TURN OFF THE HYDRAULIC POWER UNIT, DISCONNECT THE HYDRAULIC LINES AND TAG OUT THE HPU CONTROL BEFORE LUBRICATING THE FLOORHAND.. FAILURE TO DO SO MAY CAUSE INJURY TO PERSONNEL OR DAMAGE TO THE EQUIPMENT.*

Multipurpose grease, e.g.:  
Shell Alvania RL 3  
Aviaticon XRF NLGI 0

Alternatively; use EP gear lubricating grease for greasing "non-oil tight gear trains"  
NESSOS SFO  
NLGI 0  
DIN 51 826 GPOF-25  
DIN 51 502 GPOF-25

For environments in the range of 65 to 95 degrees Fahrenheit or 18 to 35 degrees Celsius, we recommend using a mineral / based lubricant such as ISO 68 or equivalent.


## Lubrication

The FloorHand should be inspected and greased each week. For higher ambient temperature up to 86° Fahrenheit (30° Celsius) we recommend to use NLGI grade 2. The grease points are:


The grease points are:

1. Die Blocks - Actuate both lower wrench clamp and upper wrench clamp to expose the grease fittings before turning off the hydraulic power unit. Use a grease gun on each of the 4 fittings (Front and back) on each die block to lubricate the centering buttons.
2. Die Blocks - With the Die Blocks extended, brush grease on the top, bottom and sides of each die block.
3. Spinner gears - Brush grease onto the drive gear teeth. Take care to keep grease off of the drive rollers.
4. Torque cylinder pins - Use a grease gun on the fitting on the top of each torque cylinder pin.


5. Spinner clamp cylinder pins - Use a grease gun on the grease fitting on each end of the spinner clamp cylinder.
6. Spinner guide tubes exterior- Brush grease on the spinner guide tubes.
7. Spinner guide tubes - Use a grease gun on the grease fittings.
8. Lifting bracket (2 places) - Use a grease gun on the grease fittings.
9. Stabber (optional; no stabber available when welded frame in use) - Brush grease on the stabber guide rails and adjusting gear.
10. Stabber (optional) - Use a grease gun on the grease fitting on the bottom of each stabber locking arm.
11. Spinner clamp cylinder pins - Use a grease gun on the grease fitting on each end of the spinner clamp cylinder.
12. Die Dove Tail groove - Brush grease in the grooves.



BACKSIDE VIEW OF SPINNER ASSEMBLY



DIE BLOCK ASSEMBLY



NOTE: EXTEND DIE BLOCKS TO GREASE AT POINTED SPOTS

Figure 50

## Removal of Die-block

Procedure:

1. Remove the bolt. Number 1
2. Remove retainer. Number 2
3. Remove the retainer pin. Use the opening on the front on the wrench and push the pin through the opening on the back of the wrench. (Not shown)
4. Remove pipe stop. (Lower wrench only) Number 4
5. Remove pipe stop base. (Lower wrench only) Number 5
6. Slide out the Die Block. Number 6

## Replacement of Tong Dies

The tong dies should be inspected on a daily basis and replaced if damaged.

Actuate both lower wrench clamp and upper wrench clamp to expose the tong die retainer cotter pins before turning off the hydraulic power unit. All four tong dies may be replaced at the same time if the lower wrench clamp is fully extended and the upper wrench clamp is only partially extended.

1. Remove the cotter pin securing the tong die retainer.
2. Remove the tong die retainer.
3. Slide the tong die upwards to disengage from the slot in the jaw. If the die is difficult to remove, use a brass drift to tap it out from the bottom.
4. Discard old tong dies and cotter pins.



Figure 52




Figure 53

5. Clean and grease the die slot.
6. Slide in new tong dies.
7. Replace tong die retainers.
8. Insert new cotter pins and bend legs to secure.

## Replacement of Centering Buttons

Procedure: Figure 54

1. Remove the die block as described on page 53.
2. Use a ½" drive ratchet to remove the spring retainer plug, the spring spacer and the spring.
3. Now use a mallet to drive the button back through and out of the housing.
4. Remove all debris.
5. Apply lubricant and reinstall components.
6. Replace the button and assemble in reverse order.




Figure 54

**WARNING: NEVER STRIKE THE TONG DIES WITH A HAMMER OR ANY OTHER STEEL TOOL WHEN REPLACING THE TONG DIES ON THE FLOORHAND. TONG DIES ARE HIGHLY HEAT TREATED AND BRITTLE AND MAY SHATTER. ALWAYS WEAR PROTECTIVE EYEWEAR WHEN CHANGING TONG DIES.**

**WARNING: BE AWARE OF THE FACT THERE IS A SLIGHTLY PRELOADED SPRING BEHIND THE PLUG WHICH COULD CAUSE INJURY.**

**WARNING: ALWAYS TURN OFF THE HYDRAULIC POWER UNIT, DISCONNECT THE HYDRAULIC LINES AND TAG OUT THE H.P.U CONTROL BEFORE REPLACING TONG DIES ON THE FLOORHAND.**

**WARNING: THE BLOCK IS HEAVY, TAKE CARE WHILE LIFTING.**

*WARNING: ALWAYS TURN OFF THE HYDRAULIC POWER UNIT AND DISCONNECT THE HYDRAULIC LINES BEFORE REPLACING SPINNER DRIVE ROLLERS ON THE FLOORHAND.*

## Replacing Spinner Drive Rollers

The spinner drive rollers should be inspected after each trip and replaced if they show signs of deterioration or cracking. To replace the spinner drive rollers refer to Figure 54 on page 57 and follow the procedure. For additional help refer to the full size image and explanation of parts on page 73:

1. Remove the five bolts securing the drive roller shaft retainer plate. (Items 40 and 41)
2. Remove the drive roller shaft retainer plate. (Item 17)
3. Pull the drive roller shaft (Item 16) upwards approximately  $\frac{3}{4}$ " so that the bottom end of the drive roller shaft clears the bottom plate of the spinner frame.
4. Withdraw the entire assembly from the spinner frame. Hold together the gear, roller and shaft as to not drop the parts. (Items 14, 15 and 16 respectively)
5. Remove and set aside the upper spacer for reuse. (Item 13)
6. Withdraw the drive roller shaft fully from the top of the drive roller and set aside for reuse.
7. Separate the drive roller away from the drive gear and set aside. (Items 15 and 14)
8. Clean the top of the drive roller gear to remove caked drilling mud and other debris that might keep the drive roller from fully seating in the case.
9. Inspect the drive gear bearings and replace if they appear damaged or do not rotate smoothly.
10. Lubricate the top hex of the spinner drive gear.
11. Slide the new drive roller onto the hex portion until it seats fully.
12. Clean and lubricate the drive roller shaft. Slide it through the drive roller bearings and then through the drive gear bearings. Do not use force. If the drive roller shaft does not slide easily through the bearings with, **at most**, a light tap with a hammer handle, inspect the shaft for damage and, if necessary, replace the drive roller shaft.
13. Reposition the upper spacer (Item 13) on the assembly and position the lower end of



the drive roller shaft flush with (or slightly inside) the face of the lower spacer.

14. Slide the entire assembly back into the spinner frame until the drive roller shaft contacts the back of the slot in the top plate of the spinner frame.
15. Align holes, then lightly tap the drive roller shaft (Item 16) down to engage the lower end of the drive roller shaft with the bottom plate of the spinner frame. (Items 1 or 2)
16. Orient the flat on the top of the drive roller shaft (Item 16) to properly mate with the drive roller shaft retainer. (Item 17)
17. Replace the drive roller shaft retainer (Item 17) and, Install the bolts holding it to the spinner frame and tighten.




Figure 54

# Frequency

## Inspection

A thorough inspection should be carried out periodically (every 3 months) or as special circumstances may require. Before starting an inspection disconnect hydraulic system and remove all foreign materials (dirt, paint, grease, oil, scale, etc) from surface by a suitable method. After a field inspection, it is advisable to record the extent of testing and testing results. The periodic or critical load inspection may be conducted in the field. If cracks, excessive wear etc are recognized, contact Blohm + Voss Oil Tools, LLC or an authorized service company.

## Hydraulic System Inspection

Check for leakage every day. If an internal or external leakage reaches an unacceptable level, contact Blohm + Voss Oil Tools, LLC or an authorized service company.

## Dismantling Inspection

Generally, when the equipment returns to base, warehouse, etc carry out the tool inspection, immediately. Furthermore, repair it if necessary prior to it being sent on the next job. The tool should be dismantled and inspected in a suitably equipped facility for excessive wear, cracks, flaws or deformations. Corrections should be made in accordance with recommendations which can be obtained from Blohm + Voss Oil Tools, LLC.

## Check Category I (ONGOING OBSERVATION)

Observe during operation for inadequate performance

## Check List Category II (DAILY)

CHECK FOR THE FOLLOWING GENERAL ISSUES (but not limited to):

DESCRIPTION	CHECKED	SIGNATURE
1. Complete front page of check list for the records		
2. Check state of lubrication		
3. Check functioning of FloorHand as a whole remarks		
4. Check for leakage		
5. Check completeness and condition of warning plates and labels		

Remarks

CHECK FOR LOOSE ITEMS, ESPECIALLY FOR (but not limited to):

1. Shafts, bolts and retainers		
2. Assemblies		
3. Screws, bolts, nuts, washers, retainers, springs and lock wire		
4. Check for presence of centering buttons and dies		

Remarks

CHECK FOR CRACKS, ELONGATION, DAMAGE AND CORROSION, ESPECIALLY FOR (but not limited to):

1. Dies		
2. Shafts, nuts, bolts		
3. Drive rollers		
4. Centring buttons		

Remarks

SUPERVISOR

DATE

## Check List Category III (EVERY 3 MONTHS)

GENERAL		
DESCRIPTION	CHECKED	SIGNATURE
1 Carry out a Category II inspection		
Remarks		

## Check List Category IV (EVERY YEAR)

GENERAL		
DESCRIPTION	CHECKED	SIGNATURE
1 Carry out inspection II & III		
Remarks		

\_\_\_\_\_  
SUPERVISOR

\_\_\_\_\_  
DATE

## Periodic Inspection

The recommended schedule for inspection of the FloorHand are as follows:

- Ongoing: Inspection category I
- Daily: Inspection category II
- Every 3 months: Inspection category III
- Every 1 year: Inspection category IV

The recommended frequencies apply for equipment in use during the specified period.

## Inspection Categories

This is Category III inspection plus further inspection for which the equipment is disassembled to the extent necessary to conduct NDT of all primary-load-carrying components.

Equipment shall be:

- Disassembled in a suitable-equipped facility to the extent necessary to permit full inspection of all primary-load-carrying components and other components that are critical to the equipment.
- Inspected for excessive wear, cracks, flaws and deformation.

Procedure:

- Corrections shall be made in accordance with the manufacturer's recommendations.
- Prior to inspection, all foreign material such as dirt, paint, grease, oil, scale, etc. shall be removed from the concerned parts by a suitable method (e.g. paint-stripping, steam-cleaning, grit-blasting)

# Inspection Check Lists

CHECK LIST FRONT PAGE

TYPE OF EQUIPMENT

SERIAL NUMBER

PART NUMBER

SUPERVISOR

DATE OF INSPECTION

INSPECTION CATEGORY

PLACE OF INSPECTION



## SPARE PARTS

## Recommended Spare Parts for One Year Operation

Item	Part number	Description	Qty.
1	9FH-01407	DOUBLE DRIVE ROLLER ASSEMBLY	8
2	9FH-01408	DRIVE ROLLER GEAR ASSEMBLY	2
3	9FH-01315	UPPER SPACER (DR)	4
5	9FH-01287	IDLER GEAR ASSEMBLY	2
6	9FH-01384	DRIVE ROLLER SHAFT	4
7	9FH-01391	SPINNER IDLER SHAFT	2
8	9FH-01290	IDLER SHAFT SPACER	2
9	9FH-01216	DIE RETAINER WITH COTTER PIN	24
10	9FH-01055	DIE BLOCK RETAINING PINS	8
11	9FH-70622-1	BLUE DIAMOND TONG DIE	108
12	9FH-01023	SPINNER SLIDE BEARING	2
13	9FH-01050-1	DIE BLOCK / WRENCH SUPPORT BEARING	8
14	9FH-01149-29	TORQUE CONTROL CARTRIDGE	1
15	9G6005-3	HANDLE BRACKET FOR 9G6005 VALVE	1
16	9G6005-LK	HYDRAULIC VALVE LINKAGE KIT	1
17	9FH-01152-2	TORQUE GAUGE W/ MOUNTING RING	1
18	9FH-HCPASSM	MANIPULATOR HANDLE HOUSING ASSEMBLY	2
19	9FH-10505	MANIPULATOR HOSE KIT	1
20	9FH-10504	CONTROL VALVE HOSE KIT	1
21	9FH-10500	FRAME HOSE KIT	1
22	9FH-10501	LOWER WRENCH HOSE KIT	1
23	9FH-10502	UPPER WRENCH HOSE KIT	1
24	9FH-10503	SPINNER HOSE KIT	1

# DRAWINGS

## CANTILEVER STYLE FLOORHAND WITH 9FM-2050 HYDRAULIC CYLINDER




Figure 55

## CANTILEVER STYLE FLOORHAND WITH 9FM-2050 HYDRAULIC CYLINDER




Figure 56

Item	Qty.	Part number	Description
1	1	9FH-10001	CANTILEVER FRAME ASSEMBLY
2	1	9FM-10302	SPINNER SUB ASSEMBLY
3	1	9FH-10101	LOWER WRENCH SUB ASSEMBLY ORFS
4	1	9FH-10201	UPPER WRENCH SUB ASSEMBLY ORFS
5	1	9FM-2050	HANGER ADAPTER / LIFT CYLINDER ASSEMBLY



# CANTILEVER FRAME ASSEMBLY

## 9FH-10001




Figure 57

Item	Part number	Description	Qty.
1	9FH-01291	FRAME	1
2	9CJS2424	RBC FIBERGLIDE BEARING	4
3	9FH-01151	TORQUE CYLINDER MANIFOLD ASSEMBLY	1
4	9FH-01307-5	TORQUE MANIFOLD TAG	1
5	9FH-01018-11	FLOORHAND SN TAG	1
6	9FH-01018-12	LARGE 8X8 "FLOORHAND"TAG	2
7	9FH-01152-2	TORQUE GAUGE W/ MOUNTING RING	1
8	9FH-01533	TORQUE GAUGE GUARD	1
9	9FH-01149-8	PRESSURE REDUCING VALVE ASSEMBLY	1
10	9FH-01149-9	PRV SHUTTLE VALVE	1
11	9FH-01152-1	LOWER WRENCH FLOW DIVIDER	1
12	9FH-01152-10	PRESSURE GAUGE	1
13	9FH-01539	FLOORHAND COMBINATION MANIFOLD	1

## CANTILEVER FRAME ASSEMBLY 9FH-10001




Figure 58

Item	Part number	Description	Qty.
14	9FH-01018-6	SYSTEM PRESSURE TAG	1
15	9FH-01540	FLOORHAND RETURN MANIFOLD	1
16	9FH-01152-13	IN LINE PRESSURE FILTER ASSEMBLY	1
17	9FH-01344	FRAME BUMPER	2
18*	9FH-10010	FRAME ASSY BOLT KIT (NOT SHOWN)	1
19	9FH-10500	FRAME HOSE KIT (NOT SHOWN)	1
20	9FH-10510	FRAME FITTING KIT (NOT SHOWN)	1
21	9FH-01310	TOP COVER	1
22	9FH-01426	SHUTOFF VALVE BRACKET	1

# PRESSURE REDUCING VALVE FH-01149-8





Figure 59

Item	Part number	Description	Qty.
1	9FH-01149-8M	PRV MANIFOLD	1
2	9FH-01149-32	REDUCING VALVE CARTRIDGE	1
3	9FH-01149-45	RELIEF VALVE	1

# FLOORHAND COMBINATION MANIFOLD

## 9FH-01539




Figure 60

FLOORHAND RETURN MANIFOLD  
9FH-01540




Figure 61



## SPINNER SUB ASSEMBLY 9FH-10302




Figure 62

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	9FH-01321	DRIVE ROLLER SPINNER RIGHT HALF	1
2	9FH-01320	DRIVE ROLLER SPINNER LEFT HALF	1
3	9FH-01323	SPINNER PEDESTAL CENTER SECTION	1
4	9FH-01142-1	HYDRAULIC SPINNER MOTOR	2
5	9FH-01015	DRIVE MOTOR GEAR	2
6	9FH-01399	DRIVE MOTOR GEAR CAP	2
7	9FH-01016	SPINNER CYLINDER ROD MOUNT	1
8	9FH-01018-9	ATEX TAG	1
9	9FH-01018-8	FLOORHAND TAG	1
10	9FH-01287	IDLER GEAR ASSEMBLY	2
11	9FH-01290	IDLER SHAFT SPACER	2
12	9FH-01391	SPINNER IDLER SHAFT	2
13	9FH-01315	UPPER SPACER (DRIVE ROLLER)	4
14	9FH-01408	DRIVE ROLLER GEAR ASSEMBLY	4
15	9FH-01407	DRIVE ROLLER ASSEMBLY	4

## SPINNER SUB ASSEMBLY

### 9FH-10302

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
16	9FH-01384	DRIVE ROLLER SHAFT	4
17	9FH-01017	DRIVE ROLLER SHAFT RETAINER	2
18	9FH-01149-46	SPINNER MOTOR FLOW DIVIDER	1
19	9FH-01045-5	URETHANE SPRING	1
20	9FH-01027	SPRING CAP	1
21	9FH-01074-1	SPIN CLAMP CYLINDER	1
22	9FH-01025	SHORT SPINNER CLEVIS PIN	1
23	9FH-01026	LONG SPINNER CLEVIS PIN	1
24	9BN1133814	5/16 SAE FLAT WASHER	11
25	9BN133892	5/16 SPLIT LOCKWASHER	11
26	9BN0115055	5/16-18 X HHCS	8
27	9BN64363	1/2 X 4 SPRING ROLL PIN	2
28	9BN33822	1 SAE FLAT WASHER	1
29	9BN37192	1-8 NYLON LOCK NUT	1
30	9BN65080	1/8 X 2 COTTER PIN	2
31	9BN65153	1/4 X 4 COTTER PIN	1
32	9BN0115062	5/16-18 X 2-1/4HHCS	3
33	9BN1133893	3/8 SPLIT LOCKWASHER	2
34	9BN0115105	3/8-16 X 1 HHCS	2
35	9BN1133692	5/8 HI COLLAR LOCKWASHER	8
36	9BN1123512	5/8-11 X 2-1/4 SHCS (DRILLED)	8
37	9BN60104	1/8 NPT 90 DEG GREASE ZERK	2
38	9BN60102	1/8 STRAIGHT GREASE ZERK	8
39	9BN1133817	1/2 SAE WASHER	4
40	9BN1133895	1/2 SPLIT LOCKWASHER	14
41	9BN0115205	1/2-13 X 1 HHCS	10
42	9BN0115211	1/2-13 X 2 HHCS	4
43	9BN1137262	5/16-8 TYPE-C LOCKNUT	3
44	9BN1137190	3/4-10 NYLON INSERTED LOCKNUT	2
45	9BN1137187	1/2-13 NYLON LOCK NUT	4
46	9FH-10503	SPINNER HOSE KIT GEN II (NOT SHOWN)	1
47	9FH-10513	SPINNER FITTING KIT GEN II (NOT SHOWN)	1

**DOUBLE DRIVE ROLLER ASSEMBLY**  
**9FH-01407**




Figure 63

Item	Part number	Description	Qty.
1	9FH-01382	9FH DOUBLE DRIVE ROLLER	1
2	9FH-22208	DRIVE ROLLER BEARING	2
3	9FH-01385	DRIVE ROLLER BEARING SPACER	1
4	9G2351-314	RETAINING RING	1

# IDLER GEAR ASSEMBLY 9FH-01287




Figure 64

Item	Part number	Description	Qty.
1	9FH-01288	IDLER GEAR	1
2	9FH-22207	IDLER GEAR BEARING	2
3	9FH-WH283	IDLER GEAR RETAINING RING	1
4	9FH-01398	IDLER GEAR BEARING SPACER	1

# DRIVE ROLLER GEAR ASSEMBLY 9FH-01408




Figure 65

Item	Part number	Description	Qty.
1	9FH-01383	DOUBLE DRIVE ROLLER GEAR	1
2	9FH-22206	DOUBLE DRIVE RLR GEAR BEARING	2
3	9FH-01396	DRIVE ROLLER GEAR BEARING SPACER	1
4	9FH-01314	LOWER DRIVE ROLLER GEAR SPACER	1
5	9FH-WH244	DRIVE ROLLER GEAR RETAINING RING	2



# UPPER WRENCH SUB ASSEMBLY ORFS

## 9FH-10201




Figure 66

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	9FH-01029	UPPER WRENCH WELDMENT	1
2	9FH-01520	REMOVABLE SPINNER POST ASSEMBLY	1
3	9FH-01074-2	CLAMP CYLINDER	2
4	9FH-01060	DIE BLOCK ASSEMBLY	2
5	9FH-01055	DIE BLOCK RETAINING PINS	2

## UPPER WRENCH SUB ASSEMBLY ORFS

### 9FH-10201

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
6	9FH-01056	DIE BLOCK PIN RETAINER	2
7	9FH-01023	SPINNER SLIDE BEARING	2
8	9FH-01022	POST WASHER	2
9	9FH-01150	UPPER CLAMP MANIFOLD ASSEMBLY	1
10	9FH-01058	UPPER MANIFOLD BRACKET	1
11	9FH-01074-5	TORQUE CYLINDER	1
12	9FH-01051	LONG TORQUE CYLINDER PIN	1
13	9FH-01052	SHORT TORQUE CYLINDER PIN	1
14	9FH-01378	VALVE MOUNT	1
15	9FH-01552	VALVE MOUNT BRACKET GEN II	1
16	9FH-01149-73	5 STATION V20 CONTROL VALVE	1
17	9FH-01512	CONTROL VALVE GUARD	1
18	9FH-01018-1	CONTROL VALVE TAG	1
19	9FH-01555	LOWER WRENCH HANDLE GEN II	1
20	9FH-01556	UPPER WRENCH HANDLE GEN II	1
21	9FH-01557	SPIN CLAMP HANDLE	1
22	9FH-01558	TORQUE HANDLE GEN II	1
23	9FH-01559	SPIN IN/OUT HANDLE GEN II	1
24	9FH-01071	VALVE HANDLE SHAFT	1
25	9FH-01149-2	MANIPULATOR VALVE (2 BANK)	1
26	9FH-01307-2	EXTEND/LIFT MANIPULATOR VALVE TAG	1
27	9FH-01069	VALVE HANDLE, MANIPULATOR (F)	2
28	9BV70751	SAFETY HANDLE	2
29	9FH-01096	HANDLE BRACKET WELDMENT	1
30	9FH-01101	CONTROL VALVE COVER	1
31	9BN1137264	3/8-16 TYPE-C LOCK NUT	6
32	9BN1137187	1/2-13 NYLON LOCK NUT	1
33	9BN1137262	5/16-8 TYPE-C LOCKNUT	9
34	9BN1137185	3/8-16 NYLON LOCK NUT	2
35	9BN24295	3/8-16 X 3-1/2 FHSCS	2
36	9BN18519	1-1/8-12 x 4 HHCS DRILLED (CYLINDER BLOTS)	8
37	9BN1133817	1/2 SAE WASHER	8

## UPPER WRENCH SUB ASSEMBLY ORFS

### 9FH-10201

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
38	9BN1133895	1/2 SPLIT LOCKWASHER	10
39	9BN0115205	1/2-13 X 1 HHCS	2
40	9BN0115207	1/2-13 X 1-1/4 HHCS	8
41	9BN1133893	3/8 SPLIT LOCKWASHER	6
42	9BN24295	3/8-16 X 3-1/2 FHSCS	2
43	9BN66004	3/16 X 3/4 CLEVIS PIN	5
44	9BN65016	1/16 X 1 COTTER PIN	5
45	9BN1133814	5/16 SAE FLAT WASHER	8
46	9BN133892	5/16 SPLIT LOCKWASHER	9
47	9BN0115057	5/16-18 X 1-1/4 HHCS	2
48	9BN0115059	5/16-18 X 1-1/2 HHCS	2
49	9BN0115055	5/16-18 X 1 HHCS	2
50	9BN1133815	3/8 SAE WASHER	8
51	9BN0115105	3/8-16 X 1 HHCS	4
52	9BN65153	1/4 X 4 COTTER PIN	2
53	9BN60102	1/8 STRAIGHT GREASE ZERK	2
54	9BN11130	3/8-16 x 8-1/2 HHCS	2
55	9FH-10512	UPPER WRENCH FITTING KIT GEN II (NOT SHOWN)	1
56	9FH-10502	UPPER WRENCH HOSE KIT GEN II (NOT SHOWN)	1

# REMOVABLE SPINNER POST ASSEMBLY

## 9FH-01520




Figure 67

Item	Part number	Description	Qty.
1	9FH-01514	SPINNER POST	1
2	9FH-01515	SPINNER POST BASE ASSEMBLY	1
3	9FH-01516	SPINNER POST SPLIT COLLET	1
4	9FH-01517	SPINNER POST COLLAR	1
5	9BN1133895	1/2 SPLIT LOCKWASHER	4
6	9BN0115205	1/2-13 X 1 HHCS	4
7	9BN65153	1/4 X 4 COTTER PIN	1

## LOWER WRENCH SUB ASSEMBLY ORFS 9FH-10101




Figure 68

Item	Part number	Description	Qty.
1	9FH-01061	LOWER WRENCH WELDMENT	1
2	9FH-01074-2	CLAMP CYLINDER	2
3	9FH-01060	DIE BLOCK ASSEMBLY	2
4	9FH-01055	DIE BLOCK RETAINING PINS	2
5	9FH-01056	DIE BLOCK RETAINER	2
6	9FH-01050-1	DIE BLOCK / WRENCH SUPPORT BEARING	4
7	9FH-01102	MOUNTING BRACKET	1
8	9FH-01149-11	LOWER DIVERTER VALVE ASSEMBLY	1
9	9FH-01149-10	TORQUE MANIFOLD SHUTTLE VALVE	1
10	9FH-01329	PIPE BUMPER BASE	1
11	9FH-01330	BUMPER	1
12	9FH-01331	PIPE CLAW	1
13	9BN1137187	1/2-13 NYLON LOCK NUT	4
14	9BN1137190	3/4-10 NYLON INSERTED LOCKNUT	2



## LOWER WRENCH SUB ASSEMBLY ORFS

### 9FH-10101

Item	Part number	Description	Qty.
15	9BN1137264	3/8-16 TYPE-C LOCK NUT	2
16	9BN18519	1-1/8-12 X 4 HHCS DRILLED (CYLINDER BOLTS)	8
17	9BN0115205	1/2-13 X 1 HHCS	6
18	9BN1133895	1/2 SPLIT LOCKWASHER	6
19	9BN1133817	1/2 SAE WASHER	4
20	9BN0115217	1/2-13 X 3-1/2 HHCS	2
21	9BN0115369	3/4-10 X 4 HHCS	2
22	9BN1133898	3/4 SPLIT LOCKWASHER	2
23	9BN0115119	3/8-16 X 4 HHCS	2
24	9BN1133893	3/8 SPLIT LOCKWASHER	2
25	9BN1133891	1/4 SPLIT LOCKWASHER	4
26	9BN0115009	1/4-20 X 1-1/2 HHCS	4
27	9FH-01044	GUIDE PIN	3
28	9FH-10501	LOWER WRENCH HOSE KIT GEN II (NOT SHOWN)	1
29	9FH-10511	LOWER WRENCH FITTING GEN II (NOT SHOWN)	1
30	9FH-10110	LOWER WRENCH BOLT KIT	1

# DIE BLOCK ASSEMBLY

## 9FH-01060




Figure 69

Item	Part number	Description	Qty.
1	9FH-01059	DIE BLOCK	1
2	9FH-01053	CENTERING BUTTON	4
3	9FH-01045-2	DIE BLOCK SPRING	4
4	9FH-01057	CENTERING BUTTON SPRING SPACER	4
5	9FH-01054	SPRING RETAINER PLUG	4
6	9BN60105	1/4-28 GREASE ZERK STRAIGHT	4
7	9FH-70622-1	BLUE DIAMOND TONG DIE	1
8	9FH-01216-1	DIE RETAINER PIN ONLY	1
9	9BN65076	1/8 X 1 COTTER PIN	1
10	9FH-01050-1	"DIE BLOCK / WRENCH SUPPORT BRG"	1

# 2-7/8 ADAPTER KIT ASSEMBLY 9FH-10703




Figure 70

Item	Part number	Description	Qty.
1	9FH-70622-2	BLUE DIAMOND TONG DIE	4
2	9FH-01445	2-7/8 ADAPTER ASSEMBLY	4
3	9FH-01074-15A	LOW RANGE TORQUE CYLINDER ASSEMBLY	1

# 2-7/8 DIE BLOCK ADAPTER ASSEMBLY 9FH-01445




Figure 71

Item	Part number	Description	Qty.
1	9FH-01446	2-7/8 ADAPTER	1
2	9FH-01448	CENTERING BUTTON	4
3	9FH-01447	ADAPTER RETAINER	1
4	9FH-01449	2-7/8 ADAPTER PIN	1
5	9FH-01445-1	2-7/8 BUTTON RETAINING PIN	2
6	9BN65076	1/8 X 1 COTTER PIN	1
7	9BN65016	1/16 X 1 COTTER PIN	2

## WINCH AND MOUNTING ASSEMBLY 9FH-10701




Figure 72

Item	Part number	Description	Qty.
1	9FH-01503	WINCH	1
1a	9FH-10701-1	WINCH MOUNT ADAPTER PLATE	1
2	9FH-01504	WINCH MOUNTING PLATE	1
3	9FH-01503-1	1/4 X 30 WINCH CABLE	1
4	9FH-10614	WINCH ASSY HOSE / FITTING KIT	1
5	9BN0115105	3/8-16 X 1 HHCS	6
6	9BN1133893	3/8 SPLIT LOCKWASHER	10
7	9BN1133859	3/8 FLAT WASHER	10
8	9BN1137264	3/8-16 TYPE-C LOCK NUT	4
9	9BN0115107	3/8-16 X 1-1/4 HHCS	4
10	9BN1133895	1/2 SPLIT LOCKWASHER	3
11	9BN1137187	1/2-13 NYLON LOCK NUT	3



## SERVICE KIT 9FH-10841



Figure 73

Item	Part number	Description	Qty.
1	9FH-10842	TEST PORT HOSE / GAUGE ASSEMBLY	1
2	9FH-10843	TEST KIT STORAGE BOX	1
3	9FH-01154	FLOW METER	1
4	9FH-10844	HOSE / FITTING KIT FOR FLOW METER	1
5	9HCORBORK	ORB O-RING KIT	1
6	9HCORFSORK	ORFS O-RING KIT	1
7	9FH-01142-10SRK	MOTOR OUTPUT SHAFT REPAIR KIT	1
8	9FH-01149-1RK	CONTROL VALVE SECTION SEAL KIT	1
9	9FH-HPC2928-RK	CLAMP CYLINDER REPAIR KIT	1
10	9FH37820151RK	SPIN CLAMP CYLINDER REPAIR KIT	1
11	9FH37820145RK	LIFT CYLINDER REPAIR KIT	1
12	9FH37820123RK	TORQUE CYLINDER REPAIR KIT	1
13	9FH-HCPASSM	MANIPULATOR HANDLE HOUSING ASSEMBLY	1
14	9G6005-RK	REPAIR KIT FOR 6005 HYDRAULIC VALVE	1
15	9G6005-LK	HYDRAULIC VALVE LINKAGE KIT	1
16	9G6005-3	HANDLE BRACKET FOR G6005 VALVE	1

# LOW RANGE TORQUE CYLINDER CHART

Low Range Torque Cylinder (3 1/4" bore)





Figure 74


## FLOORHAND COMPLETE HYDRAULIC SCHEMATIC



FILE: FH-HS-10017.DWG  
DATE: 17-JUL-2011

Figure 75

# HYDRAULIC SCHEMATIC



HYDRAULIC SCHEMATIC

9GF1000 FLOORHAND SUSPENSION

FILE: FH-HS-10015.DWG  
DATE: 11MAY2011

Figure 76

## INDEX



1-1/8-12 X 4 HHCS DRILLED (CYL)	83
1/2-13 NYLON LOCK NUT	74, 82, 87
1/2-13 X 1 HHCS	74, 80, 81, 83
1/2-13 X 2 HHCS	74
1/2-13 X 3-1/2 HHCS	83
1/2 SAE WASHER	74, 83
1/2 SPLIT LOCKWASHER	74, 80, 81, 83, 87
1/2 X 4 SPRING ROLL PIN	74
1/4-20 X 1-1/2 HHCS	83
1/4-28 GREASE ZERK STRAIGHT	84
1/4 SPLIT LOCKWASHER	83
1/4 X 4 COTTER PIN	74, 80, 81
1/4 X 30 WINCH CABLE	87
1-8 NYLON LOCK NUT	74
1/8 STRAIGHT GREASE ZERK	74
1/8 X 1 COTTER PIN	84, 86
1/16 X 1 COTTER PIN	86
1 SAE FLAT WASHER	74
2-7/8 ADAPTER	85, 86
2-7/8 ADAPTER ASSEMBLY	85
2-7/8 ADAPTER PIN	86
2-7/8 BUTTON RETAINING PIN	86
3/4-10 NYLON INSERTED LOCKNUT	74, 82
3/4-10 X 4 HHCS	83
3/4 SPLIT LOCKWASHER	83
3/8-16 TYPE-C LOCK NUT	87
3/8-16 X 1-1/4 HHCS	87
3/8-16 X 1 HHCS	74, 87
3/8-16 X 4 HHCS	83
3/8-16 x 8-1/2 HHCS	80
3/8 FLAT WASHER	87
3/8 SAE WASHER	80
3/8 SPLIT LOCKWASHER	74, 83, 87
5/8-11 X 2-1/4 SHCS (DRILLED)	74
5/8 HI COLLAR LOCKWASHER	74
5/16-8 TYPE-C LOCKNUT	74
5/16-18 X 1-1/4 HHCS	80

5/16-18 X 1 HHCS	80
5/16 SAE FLAT WASHER	74
5/16 SPLIT LOCKWASHER	74
5 STATION V20 CONTROL VALVE	79
9BN11130	80
9BN18519	83
9BN33822	74
9BN37192	74
9BN60102	74
9BN60104	74
9BN60105	84
9BN64363	74
9BN65016	86
9BN65076	84, 86
9BN65080	74
9BN65153	74, 80, 81
9BN0115009	83
9BN0115055	74
9BN0115057	80
9BN0115059	80
9BN0115062	74
9BN0115105	74, 87
9BN0115107	87
9BN0115119	83
9BN0115205	74, 80, 81, 83
9BN0115211	74
9BN0115217	83
9BN0115369	83
9BN133892	74
9BN1123512	74
9BN1133692	74
9BN1133814	74
9BN1133815	80
9BN1133817	74, 83
9BN1133859	87
9BN1133891	83
9BN1133893	74, 83, 87

9BN1133895	74, 80, 81, 83, 87
9BN1133898	83
9BN1137187	74, 82, 87
9BN1137190	74, 82
9BN1137262	74
9BN1137264	83, 87
9BV70751	79
9CJS2424	68
9FH-01015	73
9FH-01016	73
9FH-01017	74
9FH-01018-1	79
9FH-01018-6	69
9FH-01018-8	73
9FH-01018-9	73
9FH-01018-11	68
9FH-01018-12	68
9FH-01022	79
9FH-01023	64, 79
9FH-01025	74
9FH-01026	74
9FH-01027	74
9FH-01029	78
9FH-01045-2	84
9FH-01045-5	74
9FH-01050-1	64, 82, 84
9FH-01051	79
9FH-01052	79
9FH-01053	84
9FH-01054	84
9FH-01055	64, 78, 82
9FH-01056	79, 82
9FH-01057	84
9FH-01058	79
9FH-01059	84
9FH-01060	78, 82, 84
9FH-01061	82

9FH-01069	79
9FH-01071	79
9FH-01074-1	74
9FH-01074-2	78, 82
9FH-01074-5	79
9FH-01074-15A	85
9FH-01096	79
9FH-01101	79
9FH-01102	82
9FH-01142-1	73
9FH-01142-10SRK	88
9FH-01149-1RK	88
9FH-01149-2	79
9FH-01149-8	68
9FH-01149-8M	70
9FH-01149-9	68
9FH-01149-10	82
9FH-01149-11	82
9FH-01149-29	64
9FH-01149-32	70
9FH-01149-45	70
9FH-01149-46	74
9FH-01149-73	79
9FH-01150	79
9FH-01151	68
9FH-01152-1	68
9FH-01152-2	64, 68
9FH-01152-10	68
9FH-01152-13	69
9FH-01154	88
9FH-01216	64
9FH-01216-1	84
9FH-01287	64, 73, 76
9FH-01288	76
9FH-01290	64, 73
9FH-01291	68
9FH-01307-2	79

9FH-01307-5	68
9FH-01310	69
9FH-01314	77
9FH-01315	64, 73
9FH-01320	73
9FH-01321	73
9FH-01323	73
9FH-01329	82
9FH-01330	82
9FH-01331	82
9FH-01344	69
9FH-01378	79
9FH-01382	75
9FH-01383	77
9FH-01384	64, 74
9FH-01385	75
9FH-01391	64, 73
9FH-01396	77
9FH-01398	76
9FH-01399	73
9FH-01407	64, 73, 75
9FH-01408	64, 73, 77
9FH-01426	69
9FH-01445	85, 86
9FH-01445-1	86
9FH-01446	85, 86
9FH-01447	85, 86
9FH-01448	85, 86
9FH-01449	86
9FH-01503	87
9FH-01503-1	87
9FH-01504	87
9FH-01512	79
9FH-01514	81
9FH-01515	81
9FH-01516	81
9FH-01517	81



9FH-01520	78, 81
9FH-01533	68
9FH-01539	68, 71
9FH-01540	69, 72
9FH-01552	79
9FH-01555	79
9FH-01556	79
9FH-01557	79
9FH-01558	79
9FH-01559	79
9FH-10001	67, 68, 69
9FH-10010	69
9FH-10101	67, 82, 83
9FH-10110	83
9FH-10121	83
9FH-10123	83
9FH-10201	67, 78, 79, 80
9FH-10302	73, 74
9FH-10323	74
9FH-10363	74
9FH-10500	64, 69
9FH-10501	64, 83
9FH-10502	64, 80
9FH-10503	64, 74
9FH-10504	64
9FH-10505	64
9FH-10510	69
9FH-10511	83
9FH-10512	80
9FH-10513	74
9FH-10614	87
9FH-10842	88
9FH-10843	88
9FH-10844	88
9FH-22206	77
9FH-22207	76
9FH-22208	75

9FH-70622-1	64, 84, 85
9FH-70622-2	85
9FH37820123RK	88
9FH37820145RK	88
9FH37820151RK	88
9FH-HCPASSM	64, 88
9FH-HPC2928-RK	88
9FH-WH244	77
9FH-WH283	76
9FM-2050	7, 66, 67
9FM-10302	67
9G2351-314	75
9G6005-3	64, 88
9G6005-LK	64, 88
9G6005-RK	88
9GF1100 LWR WRENCH SUB ASSY ORFS	67
9GF1100 UPPER WRNCH SUB ASSY ORFS	67
9HCORBORK	88
9HCORFSORK	88
<b>A</b>	
ADAPTER RETAINER	85, 86
ATEX TAG	73
<b>B</b>	
BLUE DIAMOND TONG DIE	64, 84, 85
BUMPER	82
<b>C</b>	
CANTILEVER FRAME ASSEMBLY	8, 67, 68, 69
CENTERING BUTTON	84, 85, 86
CENTERING BUTTON SPRING SPACER	84
CLAMP CYLINDER	74, 82, 88
CLAMP CYLINDER REPAIR KIT	88
CONTROL VALVE COVER	79
CONTROL VALVE GUARD	79
CONTROL VALVE HOSE KIT	64
CONTROL VALVE SECTION SEAL KIT	88
CONTROL VALVE TAG	79

**D**

DIE BLOCK	82, 84, 86
DIE BLOCK ASSEMBLY	78, 82
DIE BLOCK PIN RETAINER	79
DIE BLOCK RETAINER	82
DIE BLOCK RETAINING PINS	64, 78, 82
DIE BLOCK SPRING	84
DIE BLOCK / WRENCH SUPPORT BEARING	64, 82
DIE RETAINER PIN ONLY	84
DIE RETAINER WITH COTTER PIN	64
DOUBLE DRIVE RLR GEAR BEARING	77
DOUBLE DRIVE ROLLER ASSEMBLY	64
DOUBLE DRIVE ROLLER GEAR	77
DRIVE MOTOR GEAR	73
DRIVE MOTOR GEAR CAP	73
DRIVE ROLLER ASSEMBLY	73
DRIVE ROLLER GEAR ASSEMBLY	64, 73
DRIVE ROLLER GEAR RETAINING RING	77
DRIVE ROLLER SHAFT	64, 74
DRIVE ROLLER SHAFT RETAINER	74

**E**

EXTEND/LIFT MANIPULATOR VALVE TAG	79
-----------------------------------	----

**F**

FH MOTOR OUTPUT SHAFT REPAIR KIT	88
FLAT WASHER	74
FLOORHAND COMBINATION MANIFOLD	68, 71
FLOORHAND RETURN MANIFOLD	69, 72
FLOORHAND SN TAG	68
FLOORHAND TAG	73
FLOW METER	88
FRAME	8, 67, 68, 69
FRAME ASSY BOLT KIT	69
FRAME BUMPER	69
FRAME FITTING	69
FRAME HOSE KIT	64, 69

**G**

H	
HANDLE BRACKET FOR G6005 VALVE	64, 88
HANDLE BRACKET WELDMENT	79
HANGER ADAPTER / LIFT CYLINDER ASSEMBLY	8, 67
HOSE / FITTING KIT FOR FLOW METER	88
HYDRAULIC SPINNER MOTOR	73
HYDRAULIC VALVE LINKAGE KIT	64, 88
I	
IDLER GEAR	73
IDLER GEAR ASSEMBLY	64, 73
IDLER SHAFT SPACER	64, 73
IN LINE PRESSURE FILTER ASSEMBLY	69
J	
K	
L	
LARGE 8X8 "FLOORHAND" TAG	68
LIFT CYLINDER REPAIR KIT	88
LOCK NUT	74, 82, 83
LOCKWASHER	74, 83
LONG SPINNER CLEVIS PIN	74
LONG TORQUE CYLINDER PIN	79
LOWER DIVERTER VALVE ASSEMBLY	82
LOWER DRIVE ROLLER GEAR SPACER	77
LOWER WRENCH BOLT KIT	83
LOWER WRENCH FITTING	83
LOWER WRENCH FLOW DIVIDER	68
LOWER WRENCH HANDLE GEN II	79
LOWER WRENCH HOSE KIT	64
LOWER WRENCH SUB ASSEMBLY ORFS	67, 82, 83
LOWER WRENCH WELDMENT	82
LOW RANGE TORQUE CYLINDER ASSEMBLY	85
M	
MANIPULATOR HANDLE HOUSING ASSEMBLY	64, 88
MANIPULATOR HOSE KIT	64
MANIPULATOR VALVE (2 BANK)	79
MOTOR OUTPUT SHAFT REPAIR KIT	88

MOUNTING BRACKET	82
<b>N</b>	
<b>O</b>	
ORB O-RING KIT	88
ORFS O-RING KIT	88
<b>P</b>	
PIPE BUMPER BASE	82
PIPE CLAW	82
POST WASHER	79
PRESSURE GAUGE	68
PRESSURE REDUCING VALVE ASSEMBLY	68
PRV MANIFOLD	70
PRV SHUTTLE VALVE	68
<b>Q</b>	
<b>R</b>	
RBC FIBERGLIDE BEARING	68
REDUCING VALVE CARTRIDGE	70
RELIEF VALVE	70, 90
REMOVABLE SPINNER POST ASSEMBLY	78
REPAIR KIT FOR 6005 HYDRAULIC VALVE	88
<b>S</b>	
SAFETY HANDLE	36, 37, 79
SHORT SPINNER CLEVIS PIN	74
SHORT TORQUE CYLINDER PIN	79
SHUTOFF VALVE BRACKET	69
SPIN CLAMP CYLINDER	74, 88
SPIN CLAMP CYLINDER REPAIR KIT	88
SPIN IN/OUT HANDLE GEN II	79
SPINNER CYLINDER ROD MOUNT	73
SPINNER HOSE	74
SPINNER HOSE KIT	64
SPINNER IDLER SHAFT	64, 73
SPINNER MOTOR FLOW DIVIDER	74
SPINNER PEDESTAL CENTER SECTION	73
SPINNER POST	78, 81
SPINNER POST BASE ASSEMBLY	81



SPINNER POST COLLAR	81
SPINNER POST SPLIT COLLET	81
SPINNER SLIDE BEARING	64, 79
SPINNER SUB ASSEMBLY	8, 67, 73, 74
SPRING CAP	74
SPRING RETAINER PLUG	84
SYSTEM PRESSURE TAG	69
<b>T</b>	
TAG	73, 79
TEST KIT STORAGE BOX	88
TEST PORT HOSE / GAUGE ASSEMBLY	88
TOP COVER	69
TORQUE CONTROL CARTRIDGE	64
TORQUE CYLINDER	79, 88
TORQUE CYLINDER MANIFOLD ASSEMBLY	68
TORQUE CYLINDER REPAIR KIT	88
TORQUE GAUGE GUARD	68
TORQUE GAUGE W/ MOUNTING RING	64, 68
TORQUE HANDLE GEN II	79
TORQUE MANIFOLD SHUTTLE VALVE	82
TORQUE MANIFOLD TAG	68
<b>U</b>	
UPPER CLAMP MANIFOLD ASSEMBLY	79
UPPER MANIFOLD BRACKET	79
UPPER SPACER (DR)	64
UPPER WRENCH FITTING KIT	80
UPPER WRENCH HANDLE GEN II	79
UPPER WRENCH HOSE KIT	64, 80
UPPER WRENCH SUB ASSEMBLY ORFS	67, 78, 79, 80
UPPER WRENCH WELDMENT	78
URETHANE SPRING	74
<b>V</b>	
VALVE HANDLE, MANIPULATOR (F)	79
VALVE HANDLE SHAFT	79
VALVE MOUNT	79
VALVE MOUNT BRACKET GEN II	79

W	
WINCH	87
WINCH ASSY HOSE / FITTING KIT	87
WINCH MOUNTING PLATE	87
X	
Y	
Z	

# World Wide Representatives for Service, Stocking and Repair



Head Office	Agent & Distributor	Agent & Distributor with Service Station	Service Station
 Germany / Hamburg	 Dubai Hungary Algeria India Italy	 U.S.A. Egypt Singapore	 Scotland / U.K. Norway Brazil Azerbaijan

## Manufacturer & Agents World Wide

Blohm + Voss Oil Tools  
Hermann-Blohm-Straße 2  
20457 Hamburg, Germany

Phone: +49(0)40/3119-1826/1162  
Fax: +49(0)40/3119-8194  
oiltools@blohmvooss.com  
www.blohmvooss-oiltools.com

Blohm + Voss Oil Tools, LLC  
7670 Woodway, Suite 266 Houston, Texas  
77063  
United States of America

Phone: +1-713-952-0266  
Fax: +1-713-952-2807  
BVOT@blohmvooss.com  
www.blohmvooss-oiltools.com

Premier Sea & Land Pte. Ltd.  
Shaw Centre  
1, Scotts Road #19-12  
228208 Singapore  
Republic of Singapore

Phone: +65-6734-7177  
Fax: +65-6734-9115  
enquiries@mtqpremier.com.sg