

Blohm + Voss Pipe Handling Equipment
BVE / BVS 750 Frame 1 air operated
4.1/2" – 14"
Technical Documentation
Original Instructions



Manual PN 710000-Y-A-D Rev 005, April 2014

Blohm + Voss Oil Tools



GENERAL INFORMATION

Warnings and Note

WARNING: A “WARNING” INDICATES A DEFINITE RISK OF EQUIPMENT DAMAGE OR DANGER TO PERSONNEL. FAILURE TO OBSERVE AND FOLLOW PROPER PROCEDURES COULD RESULT IN SERIOUS OR FATAL INJURY TO PERSONNEL, SIGNIFICANT PROPERTY LOSS, OR SIGNIFICANT EQUIPMENT DAMAGE.

NOTE: A “note” indicates that additional information is provided about the current topics.

WARNING: THIS TECHNICAL DOCUMENTATION CONTAINS INSTRUCTIONS ON SAFETY, INSTALLATION, OPERATION AND MAINTENANCE FOR THE BLOHM + VOSS OIL TOOLS TOOL .

Improper / Unsafe Use

The tool must only be used for the designated purpose. When using the tool, the rated load must never be exceeded.

IT MUST BE STUDIED BEFORE WORKING WITH THE TOOL.

Intended use of this manual

This manual is intended for use by field service, engineering, installation, operation, and repair personnel. Every effort has been made to ensure the accuracy of the information contained herein. Blohm + Voss Oil Tools, will not be held liable for errors in this material, or for consequences arising from misuse of this material. Anyone using service procedures or tools, whether or not recommended by Blohm + Voss Oil Tools, must be thoroughly satisfied that

neither personal safety nor equipment safety will be jeopardized.

Intellectual property

All rights retained. No part of this document may be reproduced in any form (print, photocopy, microfilm or any other procedure) or be processed using an electronic system without written approval of Blohm + Voss Oil Tools.

All information contained in this manual is based upon the latest product information available at any time of printing. Dependent on ongoing technical improvements (ISO 9001) “Blohm + Voss Oil Tools” reserves the right to change the design and specifications without announcement.

The values specified in this manual represent the nominal values of a unit produced in series. Slight deviations in the case of the individual devices are possible.

NOTE: In the event of problems that cannot be solved with the aid of this manual, please contact one of the addresses listed below.

CE Marking

The tool complies with the Machinery Directive 98/37/EC and 2006/42/EC

For machines containing any hydraulic or pneumatic powered parts, the Directive 94/9/EC “Equipment and protective systems in potentially explosive atmospheres” applies.

The marking is as follows: CE Ex II 2G T5 (hydraulic tools) or CE Ex II 2G T6 (pneumatic tools).

Limited Warranty

The warranty provided will be void if the tool is either:

1. Repaired or serviced by a service facility which was not authorised by Blohm + Voss Oil Tools.
2. Replacement parts not manufactured by Blohm + Voss Oil Tools are used.
3. Modifications were made to the tool which were not approved by Blohm + Voss Oil Tools.

Manufacturer & Agents World wide

Blohm + Voss Oil Tools
Hermann-Blohm-Straße 2
20457 Hamburg
Germany

Phone: +49 40/3119-1826/1162
Fax: +49 40/3119-8194
oiltools@blohmvooss.com
www.blohmvooss-oiltools.com

Blohm + Voss Oil Tools,
LLC
7670 Woodway, Suite 266
Houston,
Texas 77063
United States of America

Phone: +1-713-952 0266
Fax: +1-713-952 2807
bvot@blohmvooss.com
www.blohmvooss-oiltools.com

Premier Sea & Land Pte. Ltd.
1, Scotts Road
#19-12 Shaw Centre
Singapore 228208
Republic of Singapore

Phone: +65-6734-7177
Fax: +65-6734-9115
enquiries@mtqpremier.com.sg

General safety issues

WARNING: ONE SHOULD AVOID CREATING IGNITION SOURCES, LIKE HEAT, AS A RESULT OF THE USE OF THE TOOL WITH OTHER TOOLS OR EQUIPMENT.

WARNING: Do NOT USE THE TOOL FOR ANY OTHER PURPOSE THAN GIVEN IN THIS DOCUMENT WITHIN IT'S SPECIFICATION.

WARNING: FAILURE TO CONDUCT ROUTINE MAINTENANCE COULD RESULT IN EQUIPMENT DAMAGE OR INJURY TO PERSONNEL.

WARNING: WEAR PERSONAL PROTECTION EQUIPMENT WHILE WORKING WITH THE EQUIPMENT.

WARNING: IF ANY SAFETY ELEMENTS (LIKE SAFETY ROPES, SAFETY SHEETS, PLATES OR WASHERS) WERE DISASSEMBLED DUE TO MAINTENANCE WORK, DO NOT RE-USE THEM. ALWAYS REPLACE THEM WITH NEW SAFETY ELEMENTS.

WARNING: ALL WARNING PLATES, SIGNS AND LABELS ATTACHED TO THE EQUIPMENT MUST BE OBSERVED. THE WARNING PLATES, SIGNS AND LABELS MUST BE PRESENT ON THE TOOL. Do NOT REMOVE THE LABELS. IF THEY ARE MISSING, REPLACING IS MANDATORY.

WARNING: ANY MODIFICATION TO THE TOOL CARRIED OUT WITHOUT THE APPROVAL OF BLOHM + VOSS OIL TOOLS WILL VOID ANY WARRANTY.

WARNING: USING THE TOOL WITH DAMAGED OR WORN PARTS CAN CREATE SERIOUS INCIDENTS.

WARNING: IT IS NOT ALLOWED TO USE ANY COMPONENTS WHICH ARE OF "NON-B+V" ORIGINE, OR USE "NON-OEM" PARTS WHICH ARE NOT APPROVED BY B+V. IT WILL VOID ANY WARRANTY AND MAY EFFECT THE CORRECT FUNCTIONING OF THE TOOL AND IT'S SAFETY FEATURES.

WARNING: THE COMPANY OPERATING THE TOOL IS RESPONSIBLE FOR EVALUATING SAFE AND PROPER USE OF THE TOOL IN A HAZARD ANALYSIS.

WARNING: THE OPERATING COMPANY IS OBLIGATED TO ISSUE WORKING INSTRUCTIONS FOR SAFE USE AND SUPERVISE OBSERVANCE OF THESE WORKING INSTRUCTIONS.

20 WARNING: EVERY EMPLOYEE, WHICH OPERATES, SERVICES, INSPECTS OR OTHERWISE INVOLVED WITH THE USE OF THE TOOL IN OTHER AREAS HAS TO ENSURE, THAT THESE ACTIONS ARE DONE BY TRAINED AND BY AN BLOHM + VOSS OIL TOOLS AUTHORIZED PERSONNEL, AND SHOULD COMPLETE REGULAR COURSES OF TRAINING, TO ENSURE PROPER USE AS WELL AS SAFE OPERATION, CORRECT MAINTAINANCE AND INSPECTION.

WARNING: IF NECESSARY, A REASONABLE, ADDITIONAL SUPERVISOR SHOULD BE APPOINTED DURING OPERATION.

WARNING: STAY AWAY FROM THE TOOL DURING OPERATION. IN CASE IT IS REMOTE OPERATED IT MAY MAKE MOVEMENTS WITHOUT WARNING.

Safe handling

WARNING HANDLES/GRIP POINTS ARE MARKED BY GREEN PAINT. DURING OPERATIONS THESE GRIPS ARE THE ONLY PLACES THE TOOL CAN BE HANDLED SAFELY. IN ALL NON-GREEN MARKED PLACES THERE IS A RISK FOR INJURY. AUTOMATIC/ REMOTE OPERATED TOOLS MAY NOT HAVE ANY GREEN PAINTED GRIP-POINTS. IN THIS CASE IT IS NOT ALLOWED TO TOUCH THE TOOL WHILE OPERATING.



Safe gripping points



Warning sign PN 671638
General warning



Warning sign PN 671642
Pay attention: Apply grease at least once a day.



Warning sign PN 611524
Danger: Do not touch.



Warning sign PN 671640-1
Pay attention: Do not place your hands between moving parts.



Warning sign PN 671641
Pay attention: Risk of crushing.

Safety issues Spiders/ Elevators

WARNING: ALWAYS ENSURE THE SLIP SEGMENTS ARE LABELLED WITH THE SAME SERIAL NUMBER. NEVER USE SEGMENTS WITH DIFFERENT NUMBERS AS THEY MAY CAUSE THE PIPE TO DROP DUE TO DIFFERENT WEAR PATTERNS.

WARNING: UNDER NO CIRCUMSTANCES SHOULD THE SLIP ASSEMBLY BE RAISED WHILE SUPPORTING LOAD. IF THE SLIP ASSEMBLY IS LOWERED IN PLACE, THE TOOL CAN BEAR THE LOAD OF THE TUBULAR. BEFORE RAISING THE SLIP ASSEMBLY, MAKE SURE THAT THE TUBULAR LOAD IS SUPPORTED. THE SLIP ASSEMBLY MUST BE RELEASED FROM ANY LOAD BEFORE RAISING IT.

WARNING: YOU MUST NEITHER ASSEMBLE NOR DISASSEMBLE SLIPS, GUIDES, INSERTS, ETC. WHEN THE TOOL IS PLACED IN THE ROTARY TABLE.

WARNING: NEVER USE THE POWER SLIP/SPIDER/ ELEVATOR WITHOUT GUIDE PLATES. THIS CAN CAUSE DAMAGE TO THE SLIPS AND LEAD TO LOSS OF PIPES/ TUBULAR.

WARNING: IT MUST BE ENSURED AND CONTROLLED REGULARLY THAT THE BACK SIDE OF THE SLIPS ARE LUBRICATED WITH ENOUGH GREASE. THE QUANTITY OF GREASE MUST BE RELATED TO THE TYPE OF OPERATION AND TYPE OF MUD. FAILURE TO GREASE PROPERLY MAY LEAD TO STICKING SLIPS.

WARNING: DO NEVER UNLATCH/OPEN THE TOOL WHILE A PIPE IS SUSPENDED IN THE TOOL; THE PIPE WILL BE LOST!

WARNING: THE LIFTING OF VERTICAL PIPES IS TO BE PERFORMED CAREFULLY AND MUST BE MONITORED. THE PICKING UP OF HORIZONTAL OR TILTED PIPES IS DANGEROUS AND NOT PERMITTED BY THE MANUFACTURER.

WARNING: IF THE OPERATOR CONSIDERS TO USE THE ELEVATOR FOR OTHER OPERATIONS THAN THE INTENDED USE (FOR EXAMPLE HANDLING OF HORIZONTAL PIPES), IT IS MANDATORY TO MAKE AN ADDITIONAL RISK ANALYSIS.

WARNING: MAKE SURE ALL SLIP SEGMENTS ARE FREE IN THE UP POSITION WHEN LATCHING THE ELEVATOR. IF ANY OF THE SEGMENTS ARE STUCK IN THE DOWN POSITION, THE ELEVATOR MAY NOT CLOSE PROPERLY.

Safety issues automatic Spiders/ Elevators

WARNING: ENSURE THE CONNECTORS ARE FROM A MALE AND FEMALE TYPE TO PREVENT FAULTY CONNECTIONS.

WARNING: HYDRAULIC ONLY BEFORE ANY MAINTENANCE WORK IS CARRIED OUT, MAKE SURE THAT NO PRESSURE IS APPLIED TO THE EQUIPMENT AND THAT THE CONNECTING LINES ARE DISCONNECTED (IF APPLICABLE).

Safety issues Spiders

WARNING: YOU MUST NEITHER ASSEMBLE NOR DISASSEMBLE SLIPS, GUIDES, INSERTS, ETC. WHEN THE TOOL IS PLACED ABOVE THE WELL CENTER.

EC-DECLARATION OF CONFORMITY

We,

Blohm + Voss Oil Tools
Hermann-Blohm-Strasse 2
20457 Hamburg
Phone:+49(0)40 3119-1139
Fax:+49(0)40 3119-3305

declare that the product

Air Operated Elevator / Spider BVE / BVS 750-1 PN 710000-Y-A

which is the subject of this declaration, is in conformity with the following standard(s) or normative documents

| | |
|-------------------------|---|
| 98/37/EC: | Machinery Directive |
| DIN EN ISO 12100 : | Safety of machinery, part 1 and 2 |
| DIN EN ISO 14121-1: | Safety of machinery, Risk assessment |
| Directive 94/9/EC: | Devices and protection systems for intended use in explosive areas |
| DIN EN 13463-1:2009-07: | Non-electrical equipment for use in potentially explosive atmospheres |
| ISO 13535:2002/API 8C: | Petroleum and natural gas industries-Drilling and production equipment- |
| Hoisting | equipment |

Marking:  II 2G T5

TABLE OF CONTENTS

| | | | |
|---|-----------|---|-----------|
| GENERAL INFORMATION | 2 | 4. OPERATIONS | 24 |
| Warnings and Note | 2 | Safety | 24 |
| Intended use of this manual | 2 | Normal Operation | 24 |
| Intellectual property | 2 | Raising slips without remote control | 24 |
| Improper / Unsafe Use | 2 | Lowering slips without remote control | 24 |
| Manufacturer & Agents World wide | 2 | Emergency operation | 25 |
| CE Marking | 2 | Raising slips | 25 |
| Limited Warranty | 2 | Lowering slips | 25 |
| General safety issues | 3 | Opening the BVE/BVS 750 | 26 |
| Safe handling | 3 | Operation of the Elevator and Spider | 27 |
| Safety issues Spiders/Elevators | 4 | 5. MAINTENANCE AND INSPECTION | 30 |
| Safety issues automatic Spiders/Elevators | 4 | General | 30 |
| Safety issues Spiders | 4 | General Lubrication | 30 |
| EC-DECLARATION OF CONFORMITY | 5 | Grease daily | 31 |
| TABLE OF CONTENTS | 6 | Grease quality | 31 |
| 1. DESCRIPTION | 8 | Inspection categories acc. to API RP 8B | 32 |
| General | 8 | Frequency | 32 |
| Improper / Unsafe Use | 9 | Periodic inspection | 32 |
| Limited Warranty | 9 | Non-periodic inspection | 32 |
| Unit Identification | 9 | Inspection | 32 |
| Slip Identification | 9 | Inspection of Hydraulic/Pneumatic System | 32 |
| Technical Data | 10 | Critical Load Inspection | 33 |
| Elevator Links | 10 | Dismantling Inspection | 33 |
| Work parameter | 10 | Inspection check lists | 34 |
| Contents of delivery | 10 | Check List Category I | 35 |
| Main Dimensions | 11 | Check List Category II | 37 |
| 2. COMMISSIONING | 14 | Check List Category III | 39 |
| Commissioning BVE / BVS 750 | 14 | Check List Category IV | 40 |
| Scope of supply | 14 | Wear data criteria | 41 |
| Pneumatic Characteristics | 14 | Critical Areas | 41 |
| Lubrication | 14 | Handling, storage and transport | 42 |
| Functional Manually | 14 | Storage | 42 |
| Functional Remote Control | 14 | Short term storage after use and less then 3 months | 42 |
| 3. INSTALLATION | 16 | Long term storage over 3 months | 42 |
| Lifting and transport | 16 | Preserve the tool: Grease all blank surfaces with grease: Cylinders | 42 |
| Checking Guide Plates | 16 | Handling | 42 |
| Installing Elevator | 17 | Transport | 42 |
| Mounting the elevator | 17 | 6. SIZE COMPONENTS | 44 |
| Installing elevator links | 17 | 7. DRAWINGS AND SPARE PARTS | 46 |
| Installing Spider | 18 | | |
| Mounting the spider | 18 | | |
| Air connection | 18 | | |
| Connecting manually operated BVE/BVS | 18 | | |
| Connecting remote controlled BVE/BVS | 19 | | |
| Changing slips | 20 | | |
| Changing inserts | 21 | | |
| Installation | 22 | | |
| Pneumatic Connections | 22 | | |
| Function test | 22 | | |

DESCRIPTION


1. DESCRIPTION

General


DESCRIPTION

The Blohm + Voss 750 Tons Elevator/Spider will be used for handling long, heavy strings of casings. These tools are convertible for use as casing spiders or casing elevators, and are pneumatic operated.

When dressed as an elevator the tool includes a casing guide bell (which automatically centers the pipe for positive locking of the slips) and a bottom guide plate. Auxiliary equipment needed to use the tool as a spider includes a spider adapter plate, which sits at the well center to provide a secure platform for the tool, and an upper guide plate, which functions as a pipe centering device.



Elevator with casing guide bell



Spider with spider adapter plates

Improper / Unsafe Use


The BVE / BVS 750 must only be used for the designated purpose.

When using the BVE / BVS 750, the load of 750 sh tons must never be exceeded.

Limited Warranty


The warranty provided will be void if the BVE / BVS is either:

- repaired or serviced by a service facility which was not authorised by Blohm+Voss Oil Tools.
- replacement parts not manufactured by Blohm+Voss Oil Tools are used.
- modifications were made to the BVE / BVS which were not approved by Blohm+Voss Oil Tools.



Unit Identification

The identification area clearly identifies the BVE / BVS area (manufacturer, type, material, part number, serial number, date of manufacture). It is important to keep this information ready for the purpose of servicing and repair work.



Slip Identification



Technical Data

| | |
|--|---|
| Maximum allowable working load | 750 sh tons |
| Pipe size range (i.e. Drill pipe, casing, tubing and drill collar) | 4.1/2" to 14" |
| Weight (less Slips and Guide Plate) | 5.400 kg (11.900 lbs) |
| Feedbacksignal | Pneumatic, shows slip assembly is set or raised |
| Working air pressure | Min 7 bar (100 Psi), max 10 bar (150 Psi) |
| Air Flow rate | 6,8 m ³ /min (1,8 Gpm) |
| Temperature working range ambient | - 20° C to + 40° C - 4° F to 104° F |

Elevator Links

750t - 1000t

Work parameter





| | | |
|------------|---------------------------------|--------|
| Set slip | 7 bar - 6,8 m ³ /min | 5 sec. |
| Raise slip | 7 bar - 6,8 m ³ /min | 5 sec. |

Contents of delivery

| BVE 750 Frame 1 - Elevator | | |
|--------------------------------|-----|-------------------------------|
| | Qty | Part Number |
| Body Assembly | 1 | 710000-Y-A |
| Slip Assembly | 1 | see chapter „Size Components“ |
| Casding Guide Bell | 1 | 752600 |
| Bottom Guide Plate Assembly | 1 | see chapter „Size Components“ |
| Elevator Air Hose Assembly 52' | 1 | 752822 |
| BVS 750 Frame 1 - Spider | | |
| | Qty | Part Number |
| Body Assembly | 1 | 710000-Y-A |
| Slip Assembly | 1 | see chapter „Size Components“ |
| Spider Adapter Plate | 1 | 752765-1 |
| Upper guide Assembly | 1 | see chapter „Size Components“ |
| Spider Air Hose Assembly 26' | 1 | 752823 |

Main Dimensions

DESCRIPTION



COMMISSIONING

2. COMMISSIONING

Commissioning BVE / BVS 750

Blohm + Voss strongly recommends to accomplish the BVE / BVS commissioning with the Blohm + Voss Commissioning Service.

OK Operating personnel is aware of all danger that depends on handling the B+V tool (see manual first) !

Prior to use of the Blohm+Voss Elevator / Spider following checks must be carried out:

Scope of supply

OK Cross check of all delivered parts

Pneumatic Characteristics

OK Operating pressure 7-10 bar (100-150 PSI)

OK Volumetric flow 6,8 l/min (1,8 Gpm)

Lubrication

OK Check for correct seating of Door Hinge Pins

OK Apply grease to all greasing Points (see manual) until grease is visibly coming out of the bores

OK Check Bottom guide plate, casing guide bell and securing handle on the elevator are installed and fixed properly

OK Check Upper guide plates on spider are installed and fixed properly

OK Check slips are properly installed

OK Check slips are the correct size and same serial number

Functional Manually

OK Link blocks are closed

OK Slip Assembly opens, when Lock Lever stands in „LOCK ON“ Position and Slip Lever in „SLIP UP“ Position

OK Slip Assembly closes, when Lock Lever stands in „LOCK OFF“ Position and Slip Lever in „SLIP DOWN“

Functional Remote Control

For Operation of BVE/BVS 750 with Remote Control the Slip-control-lever must be in “SLIP DOWN”-Position and the Lock-control-lever must be in “LOCK OFF”-Position.

OK Slip Assembly raising, when Pressure apply at Connection B feedback signal indicates: Elevator is open

OK Slip Assembly setting, when Pressure apply at Connection A feedback signal indicates: Elevator is closed


INSTALLATION

3. INSTALLATION

Lifting and transport

Use wire ropes with circular slings with a load carrying capacity appropriate to the weight of the elevator / spider. Only use the ears of the main body to lift the elevator / spider as shown below. The approximate weight including the slips is 5400 Kg or 11900 lbs.


WARNING: LIFT THE BVE / BVS ON THE LIFTING EYES ONLY.



Checking Guide Plates

WARNING: BEFORE START OF WORK WEAR YOUR PERSONAL PROTECTION EQUIPMENT.

Prior to installation, inspect the Upper Guide Plate on the Spider and the Bottom Guide Plate and Casing Guide Bell on the elevator. Making sure they are tightly secured to tool bodies or covers and are of the right size for the casings to be handled. Also ensure that the inserts are properly installed and they are of the correct size for the slips.



Installing Elevator


Mounting the elevator

Make sure that the Bottom Guide Plate a, Securing Handle b and the Casing Guide Bell c are installed and are of the correct size. The Upper Guide Plate must not be installed.

WARNING: KEEP DISTANCE FROM THE ELEVATOR DURING OPERATION AND TRIALS.


Installing elevator links

1. The BVE/BVS 750 fits for 4 3/4" B+V 750t and 5 1/2" B+V 1000t Elevator Links.
2. Remove the link block pin d and safety spring e and allow the link block f to swing open.
3. Place the links in the now open assembly and secure by replacing the link block pin d and safety spring e removed in the previous step. Raise the elevator in the derrick to a height sufficient to allow installation of the spider.




Elevator

A:



B:




Open the link block

Installing Spider

Mounting the spider

1. It is necessary to place the spider adapter plate g at the well center.
2. Make sure that the Upper Guide Plate h is installed. The Bottom Guide Plate and the Casing Guide Bell must not be installed.



WARNING: KEEP DISTANCE FROM THE ELEVATOR DURING OPERATION AND TRIALS.



Air connection

- A: Power supply
 B: unassigned (or Muffler)
 C: unassigned


Connecting manually operated BVE/ BVS



Connecting remote controlled BVE/BVS

If the BVE/BVS 750 is operated by a Remote Control, the BVE/BVS is controlled with a 5/2-direction control valve.

The required Pneumatic Connections and Control-valve must be carried out according to the pneumatic schedule.



NOTE: For Operation with Top Drive a special Lever-position is required:


- Slip-lever "SLIP DOWN"
- Lock-lever "LOCK OFF"

Changing slips

WARNING: FOR CHANGING THE SLIPS, THE BVE/BVS 750 MUST BE REMOVED FROM THE WELL CENTER TO AVOID THE RISK OF SMALL PARTS FALLING INTO THE BORE HOLE.

WARNING: UNDER NO CIRCUMSTANCES THE SLIP ASSEMBLY MAY BE LIFTED UNDER LOAD.

1. Remove the two screws (a) from the top of the Cover and open both Covers to expose the slip support plate.
2. Raise the slips and confirm that the slip locks are engaged.
3. Install a forged steel eyebolt (b) into the slip.
4. Support the weight of the slip by attaching an overhead lifting device (1 ton minimum capacity) to the eyebolt. Raise the slip by using the forged steel eyebolt (b) until the Slip Link (c) is horizontal.
5. Remove the Cotter Pins (d) from the slip support pins and while supporting the slip links remove the Slip Support Pins (e).
6. Lift the slip clear of the elevator/spider and place it aside.
7. Repeat for the remaining slips.




Changing slips

Changing inserts

Use separate slip assemblies for each pipe size, so all slips can be installed and changed faster and the risk of using wrong slip assemblies for the handled pipe size will be minimized.

WARNING: FOR CHANGING THE INSERTS, THE SLIP ASSEMBLY MUST BE REMOVED OF THE BVE/BVS 750 TO AVOID THE RISK OF SMALL PARTS FALLING INTO THE BVE/BVS OR BORE HOLE.



Changing inserts

1. Open the Cover and remove the slip assembly out of the BVE/BVS 750.
2. Unlock and remove the screws a then take off the Insert Retainer b.
3. Remove the upper inserts c.
4. Unscrew both screws d and pull out the load carrying ring e.
5. Remove the remaining Inserts f.
6. Grease the insert slots g with a lithium based grease.
7. Slide the new inserts f into the dovetail-shaped insert slots up to the load carrying ring, taking care to ensure that the inserts are oriented properly (the buttress-shaped tooth form must be oriented upwardly).
8. Install the load carrying ring e and both screws d Tightening torque min. 100Nm.
9. Continue to fill the slip with inserts c until all slots are filled. Begin with a half insert h per slot. If the inserts do not slide readily into the slots, it may be necessary to lightly tap them in using a brass or non-metallic rod. If more than a light force is required, do not use the insert.
10. Install the insert retainer b by using the screws a. Secure bolts with wire.
11. Change the designation of the slip assembly. The slip assembly must always have the right markings for the installed inserts.

WARNING: WHEN ASSEMBLING SLIPS, ALWAYS WEAR EYE PROTECTION AND NEVER STRIKE THE DIES WITH A HAMMER OR OTHER HARD OBJECT. FAILURE TO OBSERVE THESE SAFETY PRECAUTIONS COULD RESULT IN SERIOUS INJURY TO PERSONNEL.

WARNING: WHEN REINSTALLING INSERTS, MAKE SURE THE INSERT SLOTS ARE GREASED AND THE INSERTS TEETH ARE POINTING UPWARD. 1.

Installation

Basically the BVE / BVS has to be installed as shown in the manual.

- | | | |
|----|--------------------------|--|
| OK | <input type="checkbox"/> | Make sure the required slips are installed |
| OK | <input type="checkbox"/> | Make sure the required Guide Plates are installed before first use |
| OK | <input type="checkbox"/> | The Guide Plates are fixed with the screws |
| OK | <input type="checkbox"/> | Cover is closed |
| OK | <input type="checkbox"/> | Door is closed |

Pneumatic Connections

- | | | |
|----|--------------------------|--|
| OK | <input type="checkbox"/> | The controls are connected to the Air Power Supply |
| OK | <input type="checkbox"/> | All Pneumatic Lines are connected |

Function test

There are two possibilities to carry out the function test:

1. Elevator/Spider standing on the floor
2. Elevator/Spider installed in the links

- | | | |
|----|--------------------------|--|
| OK | <input type="checkbox"/> | Close elevator / spider |
| OK | <input type="checkbox"/> | Open elevator / spider |
| OK | <input type="checkbox"/> | Check signal elevator / spider closed if present (if applicable) |

OPERATIONS

4. OPERATIONS

Safety

- Make sure that ALL pneumatic lines are isolated before any work is carried out.
- It is recommended to have the BVE / BVS operated by the driller.
- For smooth operation, it is recommended to slightly lower the pipe with the elevator while setting the slips.
- For smooth operation, it is recommended to slightly raise the pipe with the elevator while releasing the slips.
- Do not operate without Upper guide plate and covers in place.

Normal Operation

Raising slips without remote control


1. To raise the slips, the lock control lever is moved to the „LOCK ON“ position.
2. The slip control lever is moved to the „SLIP UP“ position .
3. Until the slips are raised the slip control lever must remain in the “LOCK ON” position.
4. The slips will automatically lock in the upper position, by a mechanical locking system.

Lowering slips without remote control

1. To lower the slips, throw the slip control lever to the „SLIP UP“ position.
2. When the slip is raised, the lock control lever must shift to the „LOCK OFF“ position and hold there.
3. Now the slip control lever must throw to the „SLIP DOWN“ position.
4. The slips will automatically lock in the lower position, by a mechanical locking system.



Manual control lever



Emergency operation

In case of air supply failure, the slips can be raised and lowered manually. The locks may be manually operated using the handles extending from the knuckles through the corner covers at the slip locks.

WARNING: To PREVENT ACCIDENTS MAKE SURE THAT THE ELEVATOR / SPIDER IS DISCONNECTED FROM THE REMOTE CONTROL OR PNEUMATIC POWER SUPPLY.

WARNING: IN NO CASE SHOULD THE LOAD ON THE CENTER OF THE SLIP SUPPORT PLATE EXCEED $\frac{1}{2}$ TONS. LOADS IN EXCESS OF THIS MAY CAUSE DAMAGE TO THE SLIP SUPPORT PLATES, STANCHIONS OR OTHER COMPONENTS. SUCH DAMAGE MAY CAUSE DAMAGE TO THE PIPE OR ASSOCIATED EQUIPMENT AND COULD POSSIBLE RESULT IN INJURY OR DEATH TO RIG PERSONNEL.

Raising slips

1. First it is necessary to open the cover A and attach four straps of a $\frac{1}{2}$ tons capacity or more to the hole B of each slip support plate directly behind the slip.
2. Holding both above handles C down, ensuring that the latches pivot to allow the pin on the slip support plate to pass.
3. Raise the slips until the slip lock plungers are heard to seat.

Lowering slips


1. Hoisting upwardly on the straps supporting the slip support plates only enough to take the slip weight off of the slip lock plungers.
2. Pull upwardly on the lock handles and hold them in that position until the slips have been lowered at least 30mm before release.
3. Lower the slips until fully set around the pipe

Opening the BVE/BVS 750

If it becomes necessary, the BVE/BVS can be removed from the pipe from the side.

WARNING: To prevent accidents make sure that the elevator / spider is disconnected from the remote control or pneumatic power supply.

1. Raise the slips.
2. Disassemble the casing guide bell (if installed).
3. Remove the two screws from the cover A.
4. Unscrew the two screws and the hinge pin securing plate B.
5. Remove the exposed hinge pin by pulling upwardly on the eyebolt C.
6. Spread the body halves apart until the elevator/spider can be withdrawn from the pipe.



Operation of the Elevator and Spider

The driller, derrickman and floorman must coordinate operation of the slips in the elevator and spider so one tool is engaged around the casing before the other is disengaged. Thus, the casing is continuously suspended by one or both tools during all stages of casing handling operations.

After the first joint has been set in the spider, follow this operating procedure:

1. The floorman attaches the top end of the casing pick-up line to the lower locking arm of the hook. The pick-up line must be long enough to attach to the next joint in the V-door when the elevator is lowered to the spider.
2. In lifting the casing joint into the V-door, the floorman can use the catline or an air-wrench, or a crewman can use a hydraulic pick-up machine, if available.
3. The floorman attaches a single-joint elevator to the bottom end of the pick-up line, then he attaches the single-joint elevator to the joint in the V-door so the joint can be maneuvered to the spider for make-up.
4. The power tong operator then makes up the joint.
5. The derrickman removes the single-joint elevator or pick-up line from the top of the joint.
6. With the elevator slips locked in the up position, the derrickman guides the elevator over the top end of the joint while the driller lowers the elevator into position approximately six inches below the joint collar.
7. The derrickman then sets the elevator slips. Note: Step 2 is repeated each time Steps 5 - 7 take place.
8. Simultaneously, the driller picks up the elevator while the floorman raises the spider slips.
9. The driller then lowers the joint through the spider stopping the elevator guide bell approximately six inches above the spider.
10. The floorman sets the spider slips.
11. The driller slacks off on the elevator so its slips can be released.
12. The floorman raises the elevator slips.
13. The driller picks up the elevator to clear the next joint of casing while the floorman repeats Step 3 for the next joint.

WARNING: BE CAREFUL NOT TO HIT THE SPIDER TOP GUARD WITH THE ELEVATOR GUIDE BELL. DOING SO WILL CREATE A HAZARD FOR PERSONNEL AND COULD DAMAGE THE EQUIPMENT.

MAINTENANCE & INSPECTION

MAINTENANCE &
INSPECTION

5. MAINTENANCE AND INSPECTION

General

If cracks, excessive wear etc. is recognised, contact Blohm + Voss Oil Tools or an authorised service company.




Weldings of the castings should be done only by Blohm + Voss Oil Tools or an authorised service company in according to Blohm + Voss welding procedure.

WARNING: FOR SERVICE AND MAINTENANCE DISCONNECT THE AIR SUPPLY.

General Lubrication

When the tool is in use, the following lubrication procedure should be performed daily, or as inspection indicates:

1. Lubricate the back of the slips with heavy grease a.
2. Apply an extreme-pressure lubricant through the grease fittings on the two hinge pins b (12 greasing points).
3. Grease the four slip stanchions c (8 greasing points).
4. Grease all bolts, springs and all slides of the two latch-assemblies d once a month.
5. Grease all Bolts of Slip assembly e.
6. Grease the lower cylinder-eyes (4 greasing points) weekly f.
7. Inspect the dies periodically and replace them if necessary. Always grease the slots when installing dies. Failure to routinely grease the slots will cause the dies to stick.



GREASE DAILY



Grease daily

All greasing points, which are labelled "Grease Daily", must be greased at least once a day. It can be necessary to carry this out more often depending on use.

Grease quality

In order to achieve efficient greasing even at different environmental temperatures, we recommend the following grease types should be used (obtainable from Blohm + Voss Oil Tools): Low-Viscosity grease Type AVIATICON Grease XRF NLGI 0

Alternatively; use EP gear lubricating grease for greasing "non-oil tight gear trains"

NESSOS SF0

NLGI 0

DIN 51 826 GPOF-25

DIN 51 502 GPOF-25

For higher ambient temperature up to 30° Celsius / 86° Fahrenheit we recommend to use NLGI 2

Inspection categories acc. to API RP 8B

Category I

This category involves observing the equipment during operation for indications of inadequate performance.

When in use, equipment shall be visually inspected on a daily basis for cracks, loose fits or connections, elongation of part, and other signs of wear, corrosion or overloading. Any parts found to show cracks, excessive wear, etc., shall be removed from service for further examination.

The equipment shall be visually inspected by a person knowledgeable in that equipment and its function.

Category II

This is Category I inspection plus further inspection for corrosion, deformation, loose or missing components, deterioration, proper lubrication, visible external cracks, and adjustment.

Category II may involve some disassembly to access specific components and to identify wear that exceeds the allowable tolerances.

Category III

This is Category II inspection plus further inspection, which should include NDT of critical areas and may involve some disassembly to access specific components and to identify wear that exceeds the allowable tolerances.

Prior to inspection, all foreign material such as dirt, paint, grease, oil, scale, etc. shall be removed from the concerned parts by a suitable method (e.g. paint-stripping, steam-cleaning, grit-blasting).

Category IV

This is Category III inspection plus further inspection for which the equipment is disassembled to the extent necessary to conduct NDT of all primary-load-carrying components.

Equipment shall be:

- disassembled in a suitable-equipped facility to the extent necessary to permit full inspection of all primary-load-carrying components and other components that are critical to the equipment.
- inspected for excessive wear, cracks, flaws and deformation.

Procedure:

- Corrections shall be made in accordance with the manufacturer's recommendations.
- Prior to inspection, all foreign material such as dirt, paint, grease, oil, scale, etc. shall be removed from the concerned parts by a suitable method (e.g. paint-stripping, steam-cleaning, grit-blasting)

Frequency

Periodic inspection

The recommended schedule for inspection of all kind of

- Elevators:

| | | |
|------------|-----|---|
| Ongoing | | I |
| Daily: | II | |
| 6 Monthly: | III | |
| 1 Year: | IV | |

- Spiders:

| | | |
|------------|-----|----|
| Ongoing: | I | |
| Weekly: | | II |
| 6 Monthly: | III | |
| 1 Year: | IV | |

The recommended frequencies apply for equipment in use during the specified period.

The inspection frequencies are only recommendations. The schedule of inspection heavily depends on the following factors:

- environment
- load cycles
- regulatory requirements
- operating time
- testing
- repairs
- re manufacture

Non-periodic inspection

A complete, on-job, shut-down inspection equivalent to the periodical Category III or Category IV should be made before (if anticipated) and after critical jobs (e.g., running heavy casing / drill strings, jarring, pulling on stuck pipes and/or operating at extreme low temperatures) <-20° C (<-4° F).

Inspection

A thorough inspection should be carried out periodically (every 3 months) or as special circumstances may require. Before starting an inspection disconnect any hydraulic/ pneumatic system and remove all foreign materials (dirt, paint, grease Oil, scale, etc.) from surface by a suitable method. After a field inspection, it is advisable to record the extent of testing and testing results. Conduct the periodic or critical load inspection in the field by the crew with the supervisor. If cracks, excessive wear etc. is recognized, contact Blohm + Voss Oil Tools or an authorized service company.

Inspection of Hydraulic/ Pneumatic System

Check for leakage every day. Should internal or external leakage reach an unacceptable high level, contact Blohm + Voss Oil Tools or an authorized service company.

Critical Load Inspection

Critical loads may occur. For example: impact loads such as jarring, pulling on stuck pipe, etc. If critical loads occurred unexpectedly, conduct the inspection immediately.

Dismantling Inspection

Generally, when the equipment returns to base, warehouse, etc. Carry out the Tool inspection, immediately. Furthermore, control it prior to its being sent on the next job.

- The Tool should be dismantled and inspected in a suitably equipped facility for excessive wear, cracks, flaws or deformations.
- Corrections should be made in accordance with recommendations which can be obtained from Blohm + Voss Oil Tools.
- Weldings at the castings should be done only by Blohm + Voss Oil Tools or an authorized service company in according to Blohm+Voss welding procedure.
- When need is shown in a field inspection, dismantle the Tool and arrange an inspection in a suitably equipped facility.
- Springs should be carefully visually inspected for excessive wear and obvious weakness.

Inspection check lists

CHECK LIST FRONT PAGE

TYPE OF EQUIPMENT

SERIAL NUMBER

PART NUMBER

SUPERVISOR

DATE OF INSPECTION

INSPECTION CATEGORY

PLACE OF INSPECTION

Check List Category I

(During operation - Elevator-spider is placed at well center or hangs at the top drive, cover closed.)

GENERAL

| DESCRIPTION | CHECKED | SIGNATURE |
|--|---------|-----------|
| 1 Complete front page of check list for the records | OK | |
| 2 Check for correct size of slips, dies and guide plates | OK | |
| 3 Check correct function of slips | OK | |
| 4 Check function of feedback signal (slips set / raised) (if applicable) | OK | |
| 5 Check correct function of locking mechanism (latch assemblies) | OK | |
| 6 Check all visible greasing points | OK | |
| Remarks | | |

CHECK FOR LOOSE ITEMS, ESPECIALLY FOR:

| DESCRIPTION | CHECKED | SIGNATURE |
|--|---------|-----------|
| 1 Hinges and bolts of cover assembly | OK | |
| 2 Hinge pin and securing plate | OK | |
| 3 Link blocks and screws | OK | |
| 4 Covers and screw | OK | |
| 5 Fixation of upper guide plate (for spider) | OK | |
| 6 Screws of casing guide bell securing handle (for elevator) | OK | |
| 7 Fixation of bottom guide plate (for elevator) | OK | |
| Remarks | | |

CHECK FOR CRACKS, ELONGATION, DAMAGE AND CORROSION, ESPECIALLY FOR:

| DESCRIPTION | CHECKED SIGNATURE |
|--------------------------------------|-------------------|
| 1 BVE/BVS Body - hinges | OK |
| 2 BVE/BVS Body - ears | OK |
| 3 Hinges and bolts of Cover Assembly | OK |
| 4 Cover assembly | OK |
| 5 Upper guide plate (for spider) | OK |
| 6 Casing guide bell (for elevator) | OK |
| 7 Bottom guide plate (for elevator) | OK |
| Remarks | |

PNEUMATIC

| DESCRIPTION | CHECKED SIGNATURE |
|---|-------------------|
| 1 Check for loose fittings, pipes, valves | OK |
| 2 Check for pneumatic leaks (hoses, valves and cylinders) | OK |
| 3 Check condition of pneumatic couplings and connection hoses | OK |
| Remarks | |

SUPERVISOR

DATE

Check List Category II

BVE/BVS not placed at well center or hanging at top drive, cover and slip assembly are disassembled.

GENERAL

| DESCRIPTION | CHECKED SIGNATURE |
|---|-------------------|
| 1 Complete front page of check list for the records | OK |
| 2 Check for correct size of slips and guide plates | OK |
| 3 Check correct function of slips | OK |
| 4 Check function of feedback signals (slips set / raised) (if applicable) | OK |
| 5 Check function of lower and upper locking mechanism (latch assemblies) | OK |
| Remarks | |

CHECK FOR LOOSE ITEMS, ESPECIALLY FOR:

| DESCRIPTION | CHECKED SIGNATURE |
|--|-------------------|
| 1 Hinges and bolts of lifting assembly | OK |
| 2 Link, screwa, bolts and other parts of slip assembly | OK |
| 3 Hinge pin and securing plate | OK |
| 4 Bolts, springs and screws of latch assemblies | OK |
| Remarks | |

CHECK FOR CRACKS, ELONGATION, DAMAGE AND CORROSION, ESPECIALLY FOR:

| DESCRIPTION | CHECKED SIGNATURE |
|--|-------------------|
| 1 Slip support plate | OK |
| 2 Gliding areas for slip assemblies | OK |
| 3 Slips stanchions | OK |
| 4 Pins/bolts of lifting assembly | OK |
| 5 Latches and plungers of latch assemblies | OK |
| 6 Check the dies | OK |
| Remarks | |

GREASING

| DESCRIPTION | CHECKED SIGNATURE |
|--|-------------------|
| 1 Check that grease system and grease points get grease to all needed areas (as far as observable) – especially for: | OK |
| 2 Slip Assembly – back side | OK |
| 3 Hinges at body (12 points) | OK |
| 4 Slip stanchions (8 points) | OK |
| 5 All bolts, springs and slides of latch assembly | OK |
| 6 All bolts of slip assembly (8 points) | OK |
| 7 All lower cylinder bolts (4 points) | OK |
| Remarks | |

PNEUMATIC

| DESCRIPTION | CHECKED SIGNATURE |
|--|-------------------|
| 1 Check for loose fittings, pipes, valves | OK |
| 2 Check for pneumatic leaks of all hoses, valves and cylinders | OK |
| 3 Check condition of pneumatic couplings and connection hoses | OK |
| 4 Check pneumatic fittings and hoses of power supply | OK |
| Remarks | |

SUPERVISOR

DATE

Check List Category III

BVE/BVS not placed at well center or hanging at top drive, cover and slip assembly are disassembled.

USE CHECK LIST OF CATEGORY II WITH FOLLOWING ADDITIONAL ITEMS:

| DESCRIPTION | CHECKED SIGNATURE |
|--|-------------------|
| GENERAL | |
| 1 Check completeness and condition of warning plates and labels | OK |
| 2 Check condition of identification plate (serial number, part number, date of manufacture etc.) | OK |
| 3 Clean tool thoroughly | OK |
| NDT - INSPECTION | |
| NDT all critical areas with die penetrant | OK |
| Remarks | |

SUPERVISOR

DATE

Check List Category IV

BVE/BVS is out well center, cover and slip assembly are disassembled.

USE CHECK LIST OF CATEGORY III WITH FOLLOWING ADDITIONAL ITEMS:

| PNEUMATIC | | CHECKED | SIGNATURE |
|-----------|--|---------|-----------|
| 1 | Change all pneumatic hoses and fittings | OK | |
| 2 | Check condition of pneumatic valves and replace if necessary | OK | |
| 3 | Check condition of pneumatic pipes and replace if necessary | OK | |
| Remarks | | | |


SUPERVISOR

DATE

Wear data criteria

| Part | Dimensions | Part | Dimensions |
|----------------------------|-----------------------|--------------------|-----------------------|
| Hinge Pin Body/Door | | Lifting Ear | |
| Hinge Pin Min. DIA new | 127,6 mm / 5,024 inch | Min. new | 275,3 mm / 10,84 inch |
| Bore Max. DIA new | 128 mm / 5,039 inch | Max. worn | 269,3 mm / 10,60 inch |
| Bore Max. DIA worn | 128,7 mm / 5,067 inch | | |
| Hinge Pin Slips | | | |
| Hinge Pin Min. DIA new | 81,5 mm / 3,209 inch | | |
| Bore Max. DIA new | 82,5 mm / 3,248 inch | | |
| Bore Max. DIA worn | 83,1 mm / 3,272 inch | | |

Critical Areas



Critical area's are hatched

Handling, storage and transport

Storage

Storage of the tool requires the following measures to be taken:

- Ensure the tool is protected from water ingress
- Ensure the tool is stored in such a way, that personnel cannot be wounded by moving parts or sharp edges. If needed, secure the tool with ropes or otherwise in order to protect it from sliding due to ship movements.

Short term storage after use and less than 3 months

Preserve the tool: Grease all blank surfaces with grease: Cylinders

Preserve all other blank surfaces with Tectyl Type 864 or equivalent

Storage: Store in a dry environment with humidity max 80%.

Commissioning: Not needed

Long term storage over 3 months

Preserve the tool: Grease all blank surfaces with grease: Cylinders

Preserve all other blank surfaces with Tectyl Type 864 or equivalent

Storage: Store in a dry environment with humidity max 80%

Commissioning: As per procedure in the User Manual

Handling

Lift the tool by its lifting ears only.

Transport

When the tool is in its original crate, use a fork lift for lifting the crate only. The weight of the tool is indicated on the identification area of the tool, and also on its original transporting crate.

SIZE COMPONENTS


6. SIZE COMPONENTS

| Pipe Size | Slip Assembly | | Inserts | | Bottom Guide Assembly P/N | Upper Guide Assembly P/N |
|-----------|-------------------|--------------|---------|------|---------------------------|--------------------------|
| | Size | P/N | P/N | Qty. | | |
| 4.1/2" | 5.1/2" x 4.1/2" | 710100-221 | 350905 | 48 | 710034 | 752710 |
| 5" | 5.1/2" x 5" | 710100-223 | 350506 | 48 | 710049 | 752715 |
| 5.1/2" | 5.1/2" x 5.1/2" | 710100-224 | 350107 | 48 | 710049 | 752715 |
| 6.5/8" | 7.5/8" x 6.5/8" | 710100-228 | 350909 | 72 | 710047 | 752720 |
| 7" | 7.5/8" x 7" | 710100-229 | 350610 | 72 | | |
| 7.5/8" | 7.5/8" x 7.5/8" | 710100-231 | 350111 | 72 | 710048 | 752725 |
| 8.5/8" | 9.5/8" x 8.5/8" | 710100-234 | 350911 | 96 | 710050 | 752730 |
| 9.5/8" | 9.5/8" x 9.5/8" | 710100-236 | 350111 | 96 | 710042 | 752735 |
| | 10.3/4" x 9.5/8" | 710100-236-1 | 351011 | 120 | | |
| 9.7/8" | 10.3/4" x 9.7/8" | 710100-265 | 350811 | 120 | | |
| 10.3/4" | 10.3/4" x 11.3/4" | 710100-238-1 | 350112 | 120 | 710052 | 752740 |
| | 11.3/4" x 10.3/4" | 710100-238 | 350912 | 144 | | |
| 11.3/4" | 11.3/4" x 11.3/4" | 710100-239 | 350112 | 144 | 710054 | 752745 |
| 12.3/4" | 14" x 12.3/4" | 710100-241 | 351112 | 168 | 710053 | 752755 |
| 13.3/8" | 14" x 13.3/8" | 710100-243 | 350613 | 168 | 710055 | 752760 |
| 13.5/8" | 14" x 13.5/8" | 710100-259 | 350413 | 168 | | |
| 14" | 14" x 14" | 710100-255 | 350113 | 168 | 710059 | 752770 |

DRAWINGS & SPARE PARTS

7. DRAWINGS AND SPARE PARTS

710000-Y-A B+V Type BVE/BVS 750 Pneumatic Elevator/Spider



Pos. 7 is not shown

710000-Y-A Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|----------|-------------------------------|
| 1 | 2 | 710010 | Body |
| 2 | 2 | 710013 | Hinge Pin |
| 3 | 2 | 710019 | Link Block |
| 4 | 1 | 710900 | Latch Assembly |
| 5 | 1 | 710200 | Lifting Assembly |
| 6 | 1 | 710800-1 | Covering Assembly |
| 7 | 1 | 710600 | Pneumatic Assembly |
| 8 | 2 | 710020 | Lifting Screw |
| 9 | 20 | 70064 | Grease Fitting |
| 10 | 20 | 612518 | Protection Cap |
| 11 | 2 | 752202 | Link Block Pin |
| 12 | 2 | 752301 | Safety Spring |
| 13 | 2 | 710025 | Screw |
| 14 | 2 | 613623 | Nut |
| 15 | 2 | 612699 | Split Pin |
| 16 | 1 | 710900-1 | Latch Assembly |
| 17 | 2 | 617518 | Plate |
| 18 | 4 | 617519 | Screw |
| 19 | 4 | 617520 | Safety sheet |
| 20 | 1 | 710660 | Pneumatic Connection Assembly |
| 21 | 2 | 752336 | Security Handle |
| 22 | 1 | 752333 | Screw |
| 23 | 1 | 755325 | Lock Washer |
| 24 | 8 | 710026 | Screw |
| 25 | 8 | 752327 | Washer |


for use as Elevator

| | | |
|---|--------|-----------------------------|
| 1 | 752600 | Casing Guide Bell Assembly |
| 1 | table | Bottom Guide Plate Assembly |
| 1 | 752822 | Elevator Air Hose Assembly |

for use as Spider

| | | |
|---|--------|----------------------------|
| 1 | 752765 | Spider Adapter Plate |
| 1 | table | Upper Guide Plate Assembly |
| 1 | 752823 | Spider Air Hose Assembly |

Slip Assembly



| Name | Pos. | Part No. | Qty. | Part No. | Qty. | Part No. | Qty. |
|---------------------|------|-----------------|------|-------------|------|-----------------|------|
| Pin | 14 | 641599 | 4 | 641599 | 4 | 641599 | 4 |
| Screw | 13 | 725464 | 8 | 725464 | 8 | 725464 | 8 |
| End Stop | 12 | 710152 | 4 | 710152 | 4 | 710152 | 4 |
| Load carrying ring | 11 | 710144 | 4 | 710144 | 4 | 710144 | 4 |
| Spring straight Pin | 10 | 88240-4 | 8 | 88240-4 | 8 | 88240-4 | 8 |
| Shoulder Screw | 9 | 710431 | 8 | 710431 | 8 | 710431 | 8 |
| Slip Link | 8 | 710415 | 8 | 710415 | 8 | 710415 | 8 |
| Screw | 7 | 775056 | 8 | 775056 | 8 | 775056 | 8 |
| Split Washer | 6 | 752327 | 12 | 752327 | 12 | 752327 | 12 |
| Lifting Eye | 5 | 755116 | 4 | 755116 | 4 | 755116 | 4 |
| Screw | 4 | 710140 | 12 | 710140 | 12 | 710140 | 12 |
| Insert | 3 | 350905 | 48 | 350506 | 48 | 350107 | 48 |
| Insert Retainer | 2 | 710122 | 4 | 710122 | 4 | 710122 | 4 |
| Slip | 1 | 710160 | 4 | 710160 | 4 | 710160 | 4 |
| Rohteil | | 710160R | 4 | 710160R | 4 | 710160R | 4 |
| Assembly | | 710100-221 | | 710100-223 | | 710100-224 | |
| Size | | 5.1/2" x 4.1/2" | | 5.1/2" x 5" | | 5.1/2" x 5.1/2" | |

| Name | Pos. | Part No. | Qty. | Part No. | Qty. | Part No. | Qty. |
|---------------------|------|-----------------|------|-------------|------|-----------------|------|
| Pin | 14 | 641599 | 4 | 641599 | 4 | 641599 | 4 |
| Screw | 13 | 725464 | 8 | 725464 | 8 | 725464 | 8 |
| End Stop | 12 | 710152 | 4 | 710152 | 4 | 710152 | 4 |
| Load carrying ring | 11 | 710138 | 4 | 710138 | 4 | 710138 | 4 |
| Spring straight Pin | 10 | 88240-4 | 8 | 88240-4 | 8 | 88240-4 | 8 |
| Shoulder Screw | 9 | 710431 | 8 | 710431 | 8 | 710431 | 8 |
| Slip Link | 8 | 710415 | 8 | 710415 | 8 | 710415 | 8 |
| Screw | 7 | 775056 | 8 | 775056 | 8 | 775056 | 8 |
| Split Washer | 6 | 752327 | 12 | 752327 | 12 | 752327 | 12 |
| Lifting Eye | 5 | 755116 | 4 | 755116 | 4 | 755116 | 4 |
| Screw | 4 | 710140 | 12 | 710140 | 12 | 710140 | 12 |
| Insert | 3 | 350909 | 72 | 350610 | 72 | 350111 | 72 |
| Insert Retainer | 2 | 710125 | 4 | 710125 | 4 | 710125 | 4 |
| Slip | 1 | 710135 | 4 | 710135 | 4 | 710135 | 4 |
| Rohteil | | 710135R | 4 | 710135R | 4 | 710135R | 4 |
| Assembly | | 710100-228 | | 710100-229 | | 710100-231 | |
| Size | | 7.5/8" x 6.5/8" | | 7.5/8" x 7" | | 7.5/8" x 7.5/8" | |



| Name | Pos. | Part No. | Qty. | Part No. | Qty. | Part No. | Qty. |
|---------------------|------|-----------------|------|-----------------|------|------------------|------|
| Pin | 14 | 641599 | 4 | 641599 | 4 | 641599 | 4 |
| Screw | 13 | 725464 | 8 | 725464 | 8 | 725464 | 8 |
| End Stop | 12 | 710152 | 4 | 710152 | 4 | 710154 | 4 |
| Load carrying ring | 11 | 710137 | 4 | 710137 | 4 | 710142 | 4 |
| Spring straight Pin | 10 | 88240-4 | 8 | 88240-4 | 8 | 88240-4 | 8 |
| Shoulder Screw | 9 | 710431 | 8 | 710431 | 8 | 710431 | 8 |
| Slip Link | 8 | 710415 | 8 | 710415 | 8 | 710415 | 8 |
| Screw | 7 | 775056 | 8 | 775056 | 8 | 775056 | 8 |
| Split Washer | 6 | 752327 | 12 | 752327 | 12 | 752327 | 12 |
| Lifting Eye | 5 | 755116 | 4 | 755116 | 4 | 755116 | 4 |
| Screw | 4 | 710140 | 12 | 710140 | 12 | 710140 | 12 |
| Insert | 3 | 350911 | 96 | 350111 | 96 | 350111 | 120 |
| Insert Retainer | 2 | 710124 | 4 | 710124 | 4 | 710127 | 4 |
| Slip | 1 | 710134 | 4 | 710134 | 4 | 710130 | 4 |
| Rohteil | | 710134R | 4 | 710134R | 4 | 710130R | 4 |
| Assembly | | 710100-234 | | 710100-236 | | 710100-236-1 | |
| Size | | 9.5/8" x 8.5/8" | | 9.5/8" x 9.5/8" | | 10.3/4" x 9.5/8" | |

| Name | Pos. | Part No. | Qty. | Part No. | Qty. | Part No. | Qty. |
|---------------------|------|------------------|------|-------------------|------|-------------------|------|
| Pin | 14 | 641599 | 4 | 641599 | 4 | 641599 | 4 |
| Screw | 13 | 725464 | 8 | 725464 | 8 | 725464 | 8 |
| End Stop | 12 | 710154 | 4 | 710154 | 4 | 710155 | 4 |
| Load carrying ring | 11 | 710142 | 4 | 710142 | 4 | 710143 | 4 |
| Spring straight Pin | 10 | 88240-4 | 8 | 88240-4 | 8 | 88240-4 | 8 |
| Shoulder Screw | 9 | 710431 | 8 | 710431 | 8 | 710431 | 8 |
| Slip Link | 8 | 710415 | 8 | 710415 | 8 | 710415 | 8 |
| Screw | 7 | 775056 | 8 | 775056 | 8 | 775056 | 8 |
| Split Washer | 6 | 752327 | 12 | 752327 | 12 | 752327 | 12 |
| Lifting Eye | 5 | 755116 | 4 | 755116 | 4 | 755116 | 4 |
| Screw | 4 | 710140 | 12 | 710140 | 12 | 710140 | 12 |
| Insert | 3 | 350811 | 120 | 350112 | 120 | 350912 | 144 |
| Insert Retainer | 2 | 710127 | 4 | 710128 | 4 | 710128 | 4 |
| Slip | 1 | 710130 | 4 | 710130 | 4 | 710131 | 4 |
| Rohteil | | 710130R | 4 | 710130R | 4 | 710130R | 4 |
| Assembly | | 710100-265 | | 710100-238-1 | | 710100-238 | |
| Size | | 10.3/4" x 9.7/8" | | 10.3/4" x 10.3/4" | | 11.3/4" x 10.3/4" | |

| Name | Pos. | Part No. | Qty. | Part No. | Qty. | Part No. | Qty. |
|---------------------|------|-------------------|------|---------------|------|---------------|------|
| Pin | 14 | 641599 | 4 | 641599 | 4 | 641599 | 4 |
| Screw | 13 | 725464 | 8 | 725464 | 8 | 725464 | 8 |
| End Stop | 12 | 710155 | 4 | 710151 | 4 | 710151 | 4 |
| Load carrying ring | 11 | 710143 | 4 | 710136 | 4 | 710136 | 4 |
| Spring straight Pin | 10 | 88240-4 | 8 | 88240-4 | 8 | 88240-4 | 8 |
| Shoulder Screw | 9 | 710431 | 8 | 710431 | 8 | 710431 | 8 |
| Slip Link | 8 | 710415 | 8 | 710415 | 8 | 710415 | 8 |
| Screw | 7 | 775056 | 8 | 775056 | 8 | 775056 | 8 |
| Split Washer | 6 | 752327 | 12 | 752327 | 12 | 752327 | 12 |
| Lifting Eye | 5 | 755116 | 4 | 755116 | 4 | 755116 | 4 |
| Screw | 4 | 710140 | 12 | 710140 | 12 | 710140 | 12 |
| Insert | 3 | 350112 | 144 | 351112 | 168 | 350613 | 168 |
| Insert Retainer | 2 | 710128 | 4 | 710123 | 4 | 710122 | 4 |
| Slip | 1 | 710131 | 4 | 710133 | 4 | 710133 | 4 |
| Rohteil | | 710130R | 4 | 710133R | 4 | 710133R | 4 |
| Assembly | | 710100-239 | | 710100-241 | | 710100-243 | |
| Size | | 11.3/4" x 11.3/4" | | 14" x 12.3/4" | | 14" x 13.3/8" | |

| Name | Pos. | Part No. | Qty. | Part No. | Qty. |
|---------------------|------|---------------|------|------------|------|
| Pin | 14 | 641599 | 4 | 641599 | 4 |
| Screw | 13 | 725464 | 8 | 725464 | 8 |
| End Stop | 12 | 710151 | 4 | 710151 | 4 |
| Load carrying ring | 11 | 710136 | 4 | 710136 | 4 |
| Spring straight Pin | 10 | 88240-4 | 8 | 88240-4 | 8 |
| Shoulder Screw | 9 | 710431 | 8 | 710431 | 8 |
| Slip Link | 8 | 710415 | 8 | 710415 | 8 |
| Screw | 7 | 775056 | 8 | 775056 | 8 |
| Split Washer | 6 | 752327 | 12 | 752327 | 12 |
| Lifting Eye | 5 | 755116 | 4 | 755116 | 4 |
| Screw | 4 | 710140 | 12 | 710140 | 12 |
| Insert | 3 | 350413 | 168 | 350113 | 168 |
| Insert Retainer | 2 | 710123 | 4 | 710123 | 4 |
| Slip | 1 | 710133 | 4 | 710133 | 4 |
| Rohteil | | 710133R | 4 | 710133R | 4 |
| Assembly | | 710100-259 | | 710100-255 | |
| Size | | 14" x 13.5/8" | | 14" x 14" | |


710900 Latch Assembly



710900 Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|----------|-----------------------|
| 1 | 1 | 710905-1 | Plate Lock Mounting 1 |
| 2 | 1 | 710310 | Latch Pin |
| 3 | 1 | 710315 | Plunger |
| 4 | 1 | 710320 | Latch |
| 5 | 1 | 710325 | Cam |
| 6 | 1 | 710930 | Knuckle |
| 7 | 1 | 710335 | Latch Spring |
| 8 | 1 | 710350 | Pin |
| 9 | 1 | 710353 | Shoulder Screw |
| 10 | 1 | 710347 | Cotter Pin |
| 11 | 1 | 710931 | Clevis Pin with head |
| 12 | 1 | 710932 | Cotter Pin |
| 13 | 2 | 710934 | Screw |
| 14 | 2 | 710933 | Nut |
| 15 | 4 | 710349 | Screw |
| 16 | 4 | 752309 | Split Washer |
| 17 | 1 | 710902 | Mounting Angle |
| 18 | 2 | 650218-3 | Washer |
| 19 | 2 | 611523 | Retaining Ring |
| 20 | 1 | 710354 | Castle Nut |
| 21 | 1 | 620609 | Cotter Pin |
| 22 | 2 | 645028 | Screw |
| 23 | 2 | 645683 | Washer |
| 24 | 1 | 710906 | Set Screw |
| 25 | 1 | 752341 | Nut |


710900-1 Latch Assembly



710900-1 Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|----------|-----------------------|
| 1 | 1 | 710905-1 | Plate Lock Mounting 1 |
| 3 | 1 | 710310 | Latch Pin |
| 4 | 1 | 710316 | Plunger |
| 5 | 1 | 710320 | Latch |
| 6 | 1 | 710325 | Cam |
| 7 | 1 | 710930 | Knuckle |
| 8 | 1 | 710335 | Latch Spring |
| 9 | 1 | 710350 | Pin |
| 10 | 1 | 710353 | Shoulder Screw |
| 11 | 1 | 710347 | Cotter Pin |
| 12 | 1 | 710931 | Clevis Pin with head |
| 13 | 1 | 710932 | Cotter Pin |
| 15 | 4 | 710349 | Screw |
| 16 | 4 | 752309 | Split Washer |
| 18 | 2 | 650218-3 | Washer |
| 19 | 2 | 611523 | Retaining Ring |
| 20 | 1 | 710354 | Castle Nut |
| 21 | 1 | 620609 | Cotter Pin |


710200 Lifting Assembly



710200 Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|----------|--------------------|
| 1 | 2 | 710405-1 | Slip Support Plate |
| 2 | 4 | 710410 | Slip Stanchion |
| 3 | 4 | 710205 | Piston Rod Link |
| 4 | 4 | 710420 | Slip Support Pin |
| 5 | 4 | 710425 | Slip Support Pin |
| 7 | 4 | 710432 | Screw |
| 8 | 8 | 622515 | Safety Spring |
| 9 | 4 | 710433 | Split Washer |
| 10 | 4 | 710427 | Screw |
| 11 | 2 | 615145 | Screw |
| 12 | 1 | 710426-1 | Indexing Bolt |


710800-1 Covering Assembly



710800-1 Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|----------|--------------|
| 1 | 1 | 710505 | Corner Cover |
| 2 | 2 | 710510 | Corner Cover |
| 3 | 1 | 710815 | Corner Cover |
| 4 | 1 | 710520 | Cover |
| 5 | 4 | 710801 | Hinge Pin |
| 6 | 24 | 82115 | Screw |
| 7 | 24 | 89125 | Nut |
| 8 | 40 | 710542 | Screw |
| 9 | 40 | 621432 | Washer |
| 10 | 2 | 710541 | Screw |

710600 Pneumatic Assembly




710600 Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|-----------|--|
| 0 | 1 | 710600-50 | Set of Pneumatic Hose Assembly for BVES 750-1 |
| 1 | 1 | 710600-51 | Pneumatic Hose Assembly for Connection "A1" |
| 2 | 1 | 710600-52 | Pneumatic Hose Assembly for Connection „A2“ |
| 3 | 1 | 710600-53 | Pneumatic Hose Assembly for Connection "A3" |
| 4 | 1 | 710600-54 | Pneumatic Hose Assembly for Connection „A4“ |
| 5 | 1 | 710600-55 | Pneumatic Hose Assembly for Connection „A5“ |
| 6 | 1 | 710600-56 | Pneumatic Hose Assembly for Connection „A6“ |
| 7 | 1 | 710600-57 | Pneumatic Hose Assembly for Connection „A7“ |
| 8 | 1 | 710600-58 | Pneumatic Hose Assembly for Connection „A8“ |
| 9 | 1 | 710600-59 | Pneumatic Hose Assembly for Connection „A9“ |
| 10 | 1 | 710600-60 | Pneumatic Hose Assembly for Connection „A10“ |
| 11 | 1 | 710600-61 | Pneumatic Hose Assembly for Connection „A11“ |
| 12 | 1 | 710600-62 | Pneumatic Hose Assembly for Connection „A12/B13“ |
| 13 | 1 | 710600-63 | Pneumatic Hose Assembly for Connection "A13" |
| 14 | 1 | 710600-64 | Pneumatic Hose Assembly for Connection "A14" |
| 15 | 1 | 710600-65 | Pneumatic Hose Assembly for Connection "A15" |
| 16 | 1 | 710600-66 | Pneumatic Hose Assembly for Connection "B1" |
| 17 | 1 | 710600-67 | Pneumatic Hose Assembly for Connection "B2" |
| 18 | 1 | 710600-68 | Pneumatic Hose Assembly for Connection „B3“ |
| 19 | 1 | 710600-69 | Pneumatic Hose Assembly for Connection "B4" |
| 20 | 1 | 710600-70 | Pneumatic Hose Assembly for Connection "B6" |
| 21 | 1 | 710600-71 | Pneumatic Hose Assembly for Connection "B7" |
| 22 | 1 | 710600-72 | Pneumatic Hose Assembly for Connection "B8" |
| 23 | 1 | 710600-73 | Pneumatic Hose Assembly for Connection "B9" |
| 24 | 1 | 710600-74 | Pneumatic Hose Assembly for Connection "B10" |
| 25 | 1 | 710600-75 | Pneumatic Hose Assembly for Connection "B11" |
| 26 | 1 | 710600-76 | Pneumatic Hose Assembly for Connection "B12" |
| 27 | 1 | 710600-77 | Pneumatic Hose Assembly for Connection "B5" |
| 28 | 1 | 710600-78 | Pneumatic Hose Assembly for Connection "B14" |
| 29 | 1 | 710600-79 | Pneumatic Hose Assembly for Connection "B15" |
| 30 | 1 | 710600-80 | Pneumatic Hose Assembly for Connection "B16" |
| 31 | 1 | 710600-81 | Pneumatic Hose Assembly for Connection "C6" |
| 32 | 1 | 710600-82 | Pneumatic Hose Assembly for Connection „C5“ |
| 33 | 1 | 710600-83 | Pneumatic Hose Assembly for Connection "C4" |
| 34 | 1 | 710600-84 | Pneumatic Hose Assembly for Connection "C1" |
| 35 | 1 | 710600-85 | Pneumatic Hose Assembly for Connection "C2" |
| 36 | 1 | 710600-86 | Pneumatic Hose Assembly for Connection "C3" |
| 37 | 8 | 710600-87 | Pneumatic Hose Assembly for Connection "A/B1" |
| 38 | 4 | 710600-88 | Pneumatic Hose Assembly for Connection "A/B2" |
| 39 | 1 | 710600-89 | Pneumatic Hose Assembly for Connection "C7" |
| 40 | 7 | 756318 | Adjustable Stud Barrel Tee |
| 41 | 3 | 755371 | Adjustable Stud Branch Tee |
| 42 | 10 | 755367 | Adjustable Stud Elbow |
| 43 | 19 | 755370 | Straight Bulkhead Coupling |
| 44 | 2 | 645105 | Straight Bulkhead Coupling |
| 45 | 14 | 755372 | Standpipe Reducer |

| Pos. | Qty. | Part no. | Description |
|------|------|----------|------------------------------|
| 46 | 19 | 755374 | Straight Male Stud Coupling |
| 47 | 1 | 615703 | Coupling |
| 48 | 1 | 613812 | Clutch Hose Coupling |
| 49 | 2 | 752828 | Plug Nipple |
| 50 | 5 | 710643 | Swivel Connection |
| 51 | 2 | 615706 | Swivel Connection |
| 52 | 6 | 613945 | Swivelling Screw Fitting |
| 53 | 1 | 645104 | T-Connection |
| 54 | 4 | 612944 | Straight Connection |
| 55 | 16 | 755373 | Straight Male Stud Coupling |
| 56 | 2 | 645096 | L-Adapter |
| 57 | 4 | 710607 | Air-Cylinder |
| 58 | 2 | 712602 | Lock Latch Cylinder Assembly |
| 59 | 2 | 612642-1 | Quick-Relief-Valve |
| 60 | 1 | 710625 | 5/2 Way Valve |
| 61 | 1 | 712617 | Shuttle valve |
| 62 | 1 | 612660 | 3/2-Way-Valve II |
| 63 | 3 | 710602 | Throttle |
| 64 | 1 | 712618 | 3/2 Way Valve |
| 65 | 1 | 710626 | 5/2 Way Valve |


710660 Pneumatic Conection Assembly



710660 Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|----------|----------------------|
| 1 | 1 | 710617 | Accessories |
| 2 | 1 | 710624 | Cylinder Mounting |
| 3 | 1 | 710611 | Cylinder Mounting |
| 4 | 2 | 710610 | Cylinder Mounting |
| 5 | 1 | 710627 | Valve Mounting |
| 6 | 1 | 710613 | Pneumatic Plate |
| 7 | 1 | 710717 | Hydraulic Plate |
| 8 | 2 | 712614 | Distance Piece |
| 9 | 2 | 712612 | Distance Piece |
| 10 | 1 | 710661 | Plate |
| 11 | 1 | 712616 | Plate |
| 12 | 2 | 643779-1 | Screw |
| 13 | 2 | 645059 | Washer |
| 14 | 8 | 725461 | Screw |
| 15 | 10 | 735854 | Washer |
| 16 | 8 | 752327 | Lock Washer |
| 17 | 8 | 710349 | Screw |
| 18 | 4 | 710639 | Clevis Pin with Head |
| 19 | 4 | 612679 | Washer |
| 20 | 4 | 752331 | Cotter Pin |
| 21 | 12 | 710543 | Spring Washer |
| 22 | 12 | 710541 | Screw |
| 23 | 2 | 87724 | Screw |
| 24 | 2 | 755251 | Nut |
| 25 | 2 | 617548 | Screw |
| 26 | 2 | 755248 | Washer |
| 27 | 2 | 726009 | Screw |
| 28 | 2 | 735309 | Lock Washer |
| 29 | 4 | 710648 | Screw |
| 30 | 4 | 710646 | Screw |
| 31 | 2 | 710647 | Screw |

752600 Casing Guide Bell Assembly



752600 Parts list

| Pos. | Qty. | Part No. | Description |
|------|------|-----------|-------------------|
| 1 | 2 | 752601 | Casing Guide Bell |
| 2 | 4 | 752329 | Screw |
| 3 | 4 | 752330 | Nut |
| 4 | 4 | 752331 | Cotter pin |
| 5 | 2 | 752337 | Screw |
| 6 | 2 | 613556-41 | Nut |
| 7 | 2 | 752339 | Cotter Pin |

752765-1 Spider Adapter Plate

